



FIXED WING SUPPORT CATALOG

PAL
PRECISION ACCESSORIES
& INSTRUMENTS
A **PAG** Company

PAL 
PRECISION ACCESSORIES
& INSTRUMENTS CANADA
A **PAG** Company

PAL 
PRECISION ACCESSORIES
& INSTRUMENTS AUSTRALIA
A **PAG** Company

PAT
PRECISION AERO TECHNOLOGY
A **PAG** Company

[CONTACT SALES & SUPPORT]



**PRECISION ACCESSORIES
& INSTRUMENTS**

495 Lake Mirror Road
Building 800
Atlanta, GA 30349
U.S.A.
(O) 404.767.5800
(F) 404.767.5900
www.precisionaccessories.com
AOG 404.218.5777
AOG@ISMRO.COM

Chris Keltner
Senior Sales Executive
404.335.7428
ckeltner@precisionaccessories.com

Shonn McCurdy
Senior Sales Executive
404.335.7435
smccurdy@precisionaccessories.com

Sarah Capati
Sales Executive
404.335.7458
scapati@ismro.com

Erica Shoemaker
Customer Experience Supervisor
404.335.7422
eshoemaker@precisionaccessories.com

Katie Gravley
Customer Experience Coordinator
404.335.7454
kgravley@precisionaccessories.com

Tamika Doucet
Customer Experience Coordinator
404.335.7456
tdoucet@precisionaviationgroup.com

Cassidy Cheek
Customer Experience Coordinator
404.335.7446
ccheek@ismro.com

Mikaela Hattaway
Customer Experience Coordinator
404.335.7440
mhattaway@ismro.com

220 Burgess Drive
Units 2, 3, 4
Broussard, LA 70518
(O) 337.714.0850
(F) 404.768.9006
www.heliparts.la
AOG 404.218.5777
AOG@ISMRO.COM

Keith Stringer
Vice President & General Manager
337.714.0851
kstringer@heliparts.com

Brent Hulin
Sales Executive
337.714.0858
bhulin@heliparts.com

Mike Shavell
Sales Executive
337.714.0862
mshavell@heliparts.com

Sabrina Sam
Sr. Customer Experience Coordinator
337.714.0856
ssam@heliparts.com

LATIN AMERICA

Av. Onófrio Milano
186, Sala 103
Jaguare, São Paulo
Brasil CEP: 05348-030
(O) 55.11.4186.6116
(F) 404.768.9006
www.heliparts.com/php-br
AOG 404.218.5777
AOG@ISMRO.COM

Juan Giraldo
Director of Sales
404.335.7421
jgiraldo@heliparts.com

Marcelo Farah
Regional Account Manager, Brazil
(O) 55.11.4186.6116
(M) 55.11.98120.6514
mfarah@heliparts.com


Christian Medina
Sales Executive
404.335.7469
cmedina@heliparts.com

Christian Pacheco
Customer Experience Coordinator
404.335.7437
cpacheco@heliparts.com

Need Rotor Wing Support?
Request a catalog or download from
www.precisionaviationgroup.com

WE'RE HIRING!

Talented, highly-motivated, and dynamic people.
Sound like you? Come join our sales team!
www.precisionaviationgroup.com/careers





Unit 7, 50 Parker Court
Pinkenba, QLD 4008
Australia
(O) 617.3198.3660
(F) 617.3198.3669
www.precisionaccessories.com.au
AOG: 614.2116.6995
AOG@ISMRO.COM

Jordan Webber
Director of Sales (Asia Pacific)
617.3198.3662
jwebber@heliparts.com

Chris Slade
Director of Operations
617.3198.3661
cslade@heliparts.com

Aaron Johnston
Sales Executive
617.3198.3664
ajohnston@precisionaviationgroup.com

Marguerite Barker
Customer Experience Coordinator
617.3198.3665
mbarker@precisionaviationgroup.com

Lisa Callan
Customer Experience Coordinator
617.3198.3667
lcallan@heliparts.com

ASIA PACIFIC

Ratan Pandey
Regional Sales Manager (SE Asia)
690 West Camp Road,
JTC Aviation 2 Building #09-07
Seletar Aerospace Park
Singapore, 797523
(O) 65.6817.3370
rpandey@heliparts.com
AOG@ISMRO.COM



Unit 305, 19133-26th Avenue
Surrey, BC V3Z-3V7
Canada
(O) 604.542.8824
(F) 604.542.8829
www.precisionaccessories.ca
AOG 778.919.8581
AOG@ISMRO.COM

Jordan Webber
Vice President & General Manager
617.3198.3662
jwebber@heliparts.com

Steve Lambert
Vice President, Business Development
604.542.8820
slambert@heliparts.com

Brian Brum
Senior Sales Executive
604.542.8820
bbrum@heliparts.com

Graham Whipple
Sales Executive
604.542.8820
gwhipple@heliparts.com

Lynette Netto
Sales Executive
604.542.8820
lnetto@heliparts.com

Heather Glancy
Business Unit Support Manager
604.542.8820
hglancy@heliparts.com

Megan Gavigan
Customer Experience Coordinator
604.542.8820
mgavigan@heliparts.com



3333 East Spring Street
Long Beach, CA 90806
(O) 562.595.6055
(F) 562.595.8416
www.precisionaerotechnology.com
AOG 562.884.1003
AOG@ISMRO.COM

Hafid Garcia
Senior Sales Executive
562.326.5127
hgarcia@pat-pag.com

John Smith
Sales, Europe
44.7808.493.723
john.smith@aerodev.co.uk

Linda Rubio
Program Manager / Repairs
562.326.5120
lrubio@pat-pag.com

Cecy Sanchez
Program Manager / Repairs
562.326.5132
csanchez@pat-pag.com

Ozzie Martinez
Customer Experience Coordinator
562.326.5134
omartinez@pat-pag.com

Rebecca Castillo
Customer Experience Coordinator
562.326.5131
rcastillo@pat-pag.com

Cassidy Cheek
Customer Experience Coordinator
404.335.7446
ccheek@ismro.com

[TABLE OF CONTENTS]

CONTACT SALES AND SUPPORT	2
AUTHORIZED DISTRIBUTOR/DEALER	5
AOG SUPPORT LOCATIONS	6
PAG CAPABILITIES	7
BENDIXKING	8
AVIONICS	11
INSTRUMENTS	14
STARTER GENERATORS	15
GENERATOR CONTROL UNITS	16
TRANSDUCERS	17
WHEELS & BRAKES	19
TACH GENERATORS	21
FUEL PUMPS	23
VACUUM PUMPS	24
DONALDSON FILTERS	24
ACCESSORIES	25
ENGINE ACCESSORIES	27

GENERAL AVIATION AIRCRAFT SUPPORT	
KING AIR	29
BEECHCRAFT	39
CESSNA	41
CITATION	45
BOMBARDIER LEARJET	51
MITSUBISHI MU-2	52
PILATUS PC-12	52
PIPER CHEYENNE	53
REGIONAL AIRLINE SUPPORT	
ATR 42 & 72	53
JETSTREAM 31/32	55
BOMBARDIER DH-8	56
BOMBARDIER CRJ	60
BEECHCRAFT 99	61
BEECHCRAFT 1900 SERIES	64
CASA 212	65
DEHAVILLAND DH-6	67
DEHAVILLAND DH-7	69
EMBRAER 120	70
DORNIER 228	76
ERJ 135/140/145	79
FAIRCHILD METROLINER	80
SAAB 340/A	82
SHORTS 330/360	83
PURCHASING INFORMATION	
WARRANTY & RETURN POLICIES	85
EXCHANGE AGREEMENT	86
END USE / USER STATEMENT	87

PAG is an Authorized **BendixKing** Service Center & Dealer!

AUTHORIZED DISTRIBUTOR/DEALER & PARTNERSHIPS

Honeywell

AEROSONIC

GOODRICH

ASPEN AVIONICS

Parker

MOOG

PPG Industries

BENZ ENGINEERING

RAPCO Inc.
REPLACEMENT AIRCRAFT PARTS CO.

GARMIN

JEPPESSEN
A BOEING COMPANY

SANDEL

SIGMA-TEK
Instruments & Avionics

AVIDYNE



UNIVERSAL AVIONICS
an Elbit Systems Company

GuardianMobility

MidContinent
INSTRUMENTS+AVIONICS

ROGERSON KRATOS

TECHNISONIC
Communications

SANDIA aerospace

KMC
KELLY MANUFACTURING COMPANY

BendixKing

MAGELLAN AEROSPACE

Rockwell Collins

SAFRAN

L3 Technologies

Collins Aerospace

AAE



UNITED INSTRUMENTS, INC.

AIRCRAFT MANUFACTURERS SUPPORTED

Beechcraft
TEXTRON AVIATION



DASSAULT AVIATION

LOCKHEED MARTIN

EMBRAER

AIRBUS



Piper

ROBINSON
HELICOPTER COMPANY


LEONARDO

TIMELY SUPPORT TO MISSION-CRITICAL OPERATORS WORLDWIDE

When you need a part, you usually need it now. In AOG situations, we can immediately dispatch an overhauled or new component to your location, from our inventory of over 100,000 line items 24/7/365.

Our trademarked **ISMRO**® (Inventory Supported Maintenance, Repair and Overhaul) business model means we stock what we service, an invaluable asset for mission-critical operators.

AOG – CALL THE LOCATION NEAREST YOU.



Atlanta, GA
404.218.5777

Peachtree City, GA
256.872.5721

Lafayette, LA
404.218.5777

Independence, KS
417.291.6201

Long Beach, CA
562.884.1003

Vancouver, BC
778.919.8581

Sao Paulo, BZ
404.218.5777

Brisbane, AU
614.2116.6995

Singapore
614.2116.6995

Others sell parts, *WE SELL SUPPORT*

PAG CAPABILITIES

PAG operates seven FAA/EASA and CASA Approved Repair Stations worldwide, a state-of-the-art Engineering Services Division, and stocks over 100,000 line items ready to ship.

92 Bench Technicians (Average Bench Experience = 19+ years) ensure that your assets are overhauled and returned quickly to keep you flying.

ACCESSORIES

Hard to find accessories made easily accessible.



PAL
Precision Aerotechnology

Call 404.768.9090 or visit us at www.heliparts.com

Avionics
Hydraulics
Instruments
Wheels & Brakes
Starter Generators

AVIONICS

Our precision service puts you back in control.



PAL
Precision Aerotechnology

Call 770.486.6061 or visit us at www.pas-pag.com

Paint
Interiors
Inspections
Maintenance
ADS-B Upgrades

INSTRUMENTS

Your source for instruments requires little navigation.




PAL
Precision Aerotechnology

Call 562.595.6055 or visit us at www.precisionaerotechnology.com

Avionics
Hydraulics
Accessories
Wheels & Brakes
Starter Generators

HYDRAULICS

Hydraulics without exertion.



PAL
Precision Aerotechnology

Call 604.542.8820 or visit us at www.heliparts.ca

Avionics
Accessories
Instruments
Wheels & Brakes
Starter Generators

STARTER GENERATORS

In the right hands, it will start a revolution.



PAL
Precision Aerotechnology

Call 617.3198.3660 or visit us at www.precisionheliparts.com.au

Avionics
Hydraulics
Accessories
Instruments
Wheels & Brakes

WHEELS & BRAKES

Wheels and brakes without the friction.



PAL
Precision Aerotechnology

Call 604.542.8824 or visit us at www.precisionaccessories.ca

Avionics
Hydraulics
Accessories
Instruments
Starter Generators



BendixKing®

FACTORY AUTHORIZED

*Audio Panels & Accessories | Autopilots & Indicators | Displays | Flight Decks
Navigation & Communication Equipment | Safety, Terrain & Radar Technology*



SERIES

DESCRIPTION

060-00013	GYRO W/TIME CONST
060-00015	GYRO MOUNT
060-00017	FLIGHT COMMAND INDICATOR
060-00026	REMOTE VERTICAL GYRO
060-00040	MULTI AXIS RATE GYRO
064-01015	HF RECEIVER
064-01016	HF CONTROLLER
064-01017	HF PA/CPLR
064-01023	VHF XCVR
064-01051	CM XCVR LCD
064-01071	HF ALE CONTROLLER
064-01084	COM XCVR
065-00015	SERVO MOUNT
065-00056	SERVO ACTUATOR
065-00060	SERVO (ROLL/YAW/PITCH)
065-00061	TRIM SERVO
065-00064	FLIGHT COMPUTER
065-00069	FLIGHT COMPUTER
065-00076	SERVO
065-00085	AIR DATA COMPUTER
065-00086	MODE CONTROLLER
065-00089	ALT SEL KFC
065-00158	AUTOPILOT COMPUTER
065-00159	MODE SELECTOR
065-00164	TRIM ADAPTER
065-00176	FLIGHT COMPUTER
065-00178	PITCH SERVO
065-00179	SERVO
065-00180	TRIM SERVO
065-00183	FCC
065-05046	TRIM ADAPTER

SERIES

DESCRIPTION

066-01021	MARKER BEACON
066-01044	MARKER BEACON
066-01048	RADAR ALTIMETER
066-01055	AUDIO PANELS
066-01066	DME
066-01067	NAV RECEIVER
066-01069	DME
066-01070	NAV RECEIVER
066-01072	ADF
066-01078	NAV RECEIVER
066-01130	NAV CONVERTER
066-01141	TRANSPONDER
066-01143	MODE S TRANSPONDER
066-01145	TCAS PROCESSOR
066-01146	TCAS II PROCESSOR
066-01152	TRAFFIC AWARENESS UNIT
066-01153	RADAR ALTIMETER
066-01156	TRANSPONDER
066-01164	TRANSPONDER
066-01171	TCAS INDICATOR
066-01175	MULTI-HAZ AWARENESS UNIT
066-01179	ELECTRONIC HSI
066-01227	EGPWS
066-03031	RADIO ALTIMETER INDICATOR
066-03034	INDICATORS
066-03044	RADAR ALTIMETER
066-03046	COMPASS SYSTEM
066-03054	RADAR ALTIMETER INDICATOR
066-03056	INDICATOR
066-03060	ADF
066-03062	SERVO ENCODING ALTIMETER

SERVICE CENTER & DEALER


SERIES

066-03064	ENCODING ALTIMETER
066-03077	ATTITUDE/VERT SPEED IND
066-03123	EFS 40/50
066-03125	EFS 40/50
066-03137	EFS 40/50
066-04031	GPS
066-04034	GPS
069-01024	NAV/COMM W/O GS
069-01025	NAV/COMM WITH GS (14v)
069-01032	NAV/COMM WITH GLIDESLOPE
069-01033	NAV/COMM (8.33)
071-00019	ADAPTERS
071-00158	EGPWS MODULE
071-00159	WEATHER RADAR MODULE
071-01234	ADF ANTENNA
071-01268	HF COM
071-01270	HF COM
071-01274	HF COM
071-01438	EFS 40/50
071-01439	EFS 40/50
071-01508	GPS
071-01511	EFS 40/50
071-01519	WEATHER RADAR
071-01548	TCAS ANTENNA
071-01550	WEATHER RADAR
071-01599	DIRECTIONAL ANTENNA
071-04037	AVIONICS COOLING FAN



MODELS SUPPORTED

ANT-67A	KDM-706A	KRA-405
ART-2000	KEA-130A	KRA-405B
ART-2100	KEA-346	KRG-333
ART-2102	KFS-578A	KS-270C
CP-466A	KFS-594	KS-271A
CP-467	KG-102A	KS-271C
CP-468	KI-202	KS-272A
CP-469	KI-203	KS-272C
CP-469A	KI-204	KSA-372
ED-461	KI-206	KSA-372X
ED-462	KI-207	KSA-470
ED-551	KI-208	KSG-105
ED-551A	KI-208A	KSM-375
IVA-81D	KI-209	KSM-375X
KA-90	KI-209A	KT-70
KA-158	KI-250	KT-71
KA-162	KI-256	KT-73
KA-33	KI-525A	KT-76C
KA-44B	KI-825	KTA-336
KA-594	KLN-90	KTA-435
KA-815	KLN-90A	KTA-810
KAC-501	KLN-90B	KTR-908
KAC-502	KLN-900	KTR-909
KA-952	KMA-24H	KTR-909A
KAS-297C	KMC-321	KTR-909B
KAV-485	KMH-820	KTR-953
KC-140	KMR-675	KVG-350
KC-225	KMS-540	KX-155
KCP-220	KN-40	KX-155A
KCP-420	KN-53	KX-165
KCP-502	KN-63	KX-165A
KCU-951	KNI-582	KY-97A
KCU-1051	KNI-415	KY-196B
KDC-222	KNR-634	MKXXI
KDI-572	KNR-634A	MST-67A
KDI-573	KR-21	TPU-66A
KDI-574	KR-87	TPU-67A



Our inventory works
to your advantage.

PAL
PRECISION ACCESSORIES
& INSTRUMENTS
A **PAG** Company

Call 404.767.5800 or visit us at
precisionaccessories.com

Hydraulics
Accessories
Instruments
Wheels & Brakes
Starter Generators

Others sell parts, WE SELL SUPPORT®



Inventory Supported
Maintenance • Repair • Overhaul

[AVIONICS]

AVTECH CAPABILITIES

PART NUM.	AIRCRAFT	DESCRIPTION
5060-1-2	ERJ	REU
5060-1-SERIES	ERJ	AUDIO CONTROL PANEL
5061-1-1 SERIES	ERJ	AUDIO CONTROL PANEL
5082-1-2	DASH 8	PA AMP
5088-1-2	DASH 8	INTERPHONE CONTROL
5090-1	EMBARER 120	REMOTE AUDIO UNIT
5091-SERIES	EMBARER 120	AUDIO CONTROL PANEL
5095-SERIES	EMBRAER 120	PA & INTERPHONE AMP
5096-SERIES	EMBRAER 120	CABIN INTERPHONES
5190-1-1	EMBRAER 120	REU
5260-1-SERIES	DASH 8	REU
5261-1-SERIES	DASH 8	AVTECH AUDIO CONTROL
5264-1-1	DASH 8	PA UNIT
5283-1-1	DASH 8	HANDSET
5361-1-3	ERJ	AUDIO CONTROL PANEL


COLLINS PANEL MOUNT

PART NUM.	MODEL	DESCRIPTION
522-2638-XXX	331A-3G	HORIZONTAL SLAVING INDICATOR
522-2644-011	328A-3G	SLAVING ACCESSORY
522-2782-004	331A-6A	HORIZONTAL SLAVING INDICATOR
522-3206-004	329B-7A	FLIGHT DIRECTOR INDICATOR
522-3306-XXX	331H-3G	COURSE SELECTOR INDICATOR
622-4565-001	332D-11T	REMOTE VERTICAL GYRO
792-6694-001	332D-11A	REMOTE VERTICAL GYRO

COLLINS REMOTE MOUNT

PART NUM.	MODEL	DESCRIPTION
522-3241-000	3.32E-02	REMOTE SLAVED GYRO
522-4114-XXX	339H-1	RADIO ALT INDICATOR
622-0137-XXX	VIR-32	NAV RECEIVER
622-0876-XXX	VIR-30	NAV RECEIVER
622-1233-001	DME-40	DME RT

AVAILABLE FOR SALE, EXCHANGE OR MRO



AVIONICS



COLLINS 332D-11 VG



COLLINS CL-22
NEW CAPABILITY



CRJ 5261 SERIES
AUDIO CONTROL PANEL



KING KY-196A
VHF COMM PANEL MOUNT

AVAILABLE FOR SALE, EXCHANGE OR MRO

COLLINS REMOTE MOUNT

PART NUM.	MODEL	DESCRIPTION
622-1270-001	VHF-21/22	VHF COMM
622-1270-001	TDR-90	ATC TRANSPONDER
622-2362-001	ADF-60A	ADF RECEIVER
622-2506-XXX	RMI-36	RMI
622-4424-001	332D-11V	REMOTE VERTICAL GYRO
622-4516-XXX	CTL-60	ADF CONTROL HEAD
622-4523-XXX	CTL-20	COMM CONTROL HEAD
622-4524-XXX	CTL-30	NAV CONTROL HEAD
622-4527-XXX	CTL-90	ATC CONTROL HEAD
622-4938-XXX	RMI-30	RMI
622-6136-001	DGS-65	SLAVED REMOTE DG
622-6263-001	DME-42	DME RT
622-6520-XXX	CTL-22	COMM CONTROL HEAD
622-6521-XXX	CTL-32	NAV CONTROL HEAD
622-6522-XXX	CTL-62	ADF CONTROL HEAD
622-6523-XXX	CTL-92	ATC CONTROL HEAD
622-6263-001	DME-42	DME RT
622-6520-XXX	CTL-22	COMM CONTROL HEAD
622-6521-XXX	CTL-32	NAV CONTROL HEAD
622-6522-XXX	CTL-62	ADF CONTROL HEAD
622-6523-XXX	CTL-92	ATC CONTROL HEAD

BENDIX/KING/HONEYWELL PANEL MOUNT

PART NUM.	MODEL	DESCRIPTION
060-0013-01	KSG-105	DIRECTIONAL GYRO
060-0017-XX	KI-256	FLIGHT DIRECTOR INDICATOR
064-1019-XX	KY-196	VHF COMM
064-1054-30	KY-196A	VHF COMM
066-1048-00	KRA-405	RADAR ALTIMETER
066-1053-00	KT-79	TRANSPONDER
066-1067-00	KN-53	NAV/GS RECEIVER
066-1072-00	KR-87	ADF RECEIVER
066-3046-05	KI-525A	HORIZONTAL SPEED INDICATOR
069-1019-00	KX-175B	VHF NAV/COMM
069-1021-00	KY-195B	VHF DUAL COMM

BENDIX/KING/HONEYWELL PANEL MOUNT

PART NUM.	MODEL	DESCRIPTION
069-1019-00	KX-175B	VHF NAV/COMM
069-1021-00	KY-195B	VHF DUAL COMM
069-1024-XX	KX-155	VHF NAV/COMM
069-1025-XX	KX-165	VHF NAV/COMM
071-1052-00	KMT-112	FLUX VALVE

SPERRY/HONEYWELL

PART NUM.	MODEL	DESCRIPTION
064-01076-0101	KTR 909B	RADIO RECEIVER-TRANSMITTER
064-1016-00	KCU-951	HIGH FREQUENCY CONTROLLER
066-01143-0201	MST-67A	TRANSPONDER
066-04028-1001	RMU-556	RADIO MANAGEMENT UNIT
066-04028-1002	RMU-556	RADIO MANAGEMENT UNIT
066-04029-0102	KDA-557	DATA ADAPTER
066-1048-02	KRA-405	RADAR ALTIMETER
066-3046-07	KI-525A	HORIZONTAL SITUATION INDICATOR
066-50024-1030	066-50024-10-30	FPD 500 FLAT PANEL DISPLAY
2587193-43	C-14A	DIRECTIONAL GYRO, REMOTE
2587193-XX	C-14	DIRECTIONAL GYROS, REMOTE
2593996-333	TARSYN-333	GYRO SYSTEM, REMOTE
2594484	FX-220	FLUX VALVE
2702-19		AIR PRESSURE REGULATOR
2801-01-3	133-380022-29	ELECTRONIC INSTR DISPLAY
345MFD1-3	133-380022-37	ELECTRONIC INSTR DISPLAY
4016341-XXX	BA-141	SERVOED ALTIMETER
4020501-XXX	GH-14 SERIES	FLIGHT DIRECTOR, ELECTRIC
4020531-XXX	GH-14 A&BS	FLIGHT DIRECTOR HORIZON
4020577-3	C-14D	DIRECTIONAL GYRO, REMOTE
4027170-90X	RD-500	H.S.I.
51538-001A	101-364270-5	GENERATOR CONTROL UNIT
622-1270-001		TRANSPONDER
7000466-XXX	AD-650B	FLIGHT DIRECTIONAL INDICATOR
7000469-XXX	RD-650A	H.S.I.
7000622-901	VG-14A	VERTICAL GYRO
7001179-912	RD-550	H.S.I.



066-3046-07
HORIZONTAL SITUATION
INDICATOR



064-1016-00
HIGH FREQUENCY
CONTROLLER



064-01076-0101
RADIO RECEIVER
TRANSMITTER



4027170-90X
H.S.I.

AVAILABLE FOR SALE, EXCHANGE OR MRO

[INSTRUMENTS]



117-94053-03
TRIPLE TACHOMETER
INDICATOR



407-375-006-101
FUEL QUALITY INDICATOR



101720
ALTIMETER



RCA1510

AVAILABLE FOR SALE, EXCHANGE OR MRO

PART NUM.	ALT PART NUM.	DESCRIPTION
10014-0000-02	8SC0051	FUEL QUANTITY INDICATOR
101450-11952	101450-11952	ENCODING ALTIMETER
10169N02R00	8SC0054	PROPELLER RPM INDICATOR
101720-11810	20K ALT LTD	ALTIMETER
102220-11886	102220-11886	ENCODING ALTIMETER
10420-11968E	10420-11968E	ALTIMETER W/PICKOFF
150-906-002	90-380009-7	FUEL FLOW TRANSMITTER
1U367-207-8	101-380036-1	ATTITUDE GYRO
1U367-232-2	101-380036-1	ATTITUDE GYRO
20020-11293	76450-00801-101	AIRSPEED INDICATOR
20130-11294	27-19193-027	MAX ALLOW AIRSPEED
20130-11341	130-380039-3	MAX ALLOW AIRSPEED
201530-11373	130-380005-7	AIRSPEED INDICATOR
20240-1189	C661063-0103	AIRSPEED INDICATOR
21140-1134-2	8SC0109	AIRSPEED INDICATOR

RC ALLEN INSTRUMENTS

PART NUM.	MODEL	DESCRIPTION
RCA11A-10	RCA11A-10	DIRECTIONAL GYRO
RCA11A-15	99003-08	DIRECTIONAL GYRO
RCA11A-3	RCA111	DIRECTIONAL GYRO
RCA11A-8	RCA11A-8	DIRECTIONAL GYRO
RCA11A-9	C661075-0103	DIRECTIONAL GYRO
RCA2	28V CANNON	TURN & SLIP
RCA22-33	114-380057-5	HORIZON
RCA2610 SERIES		DIGITAL HORIZON
RCA1510		DIGITAL HEADING INDICATOR

UNITED INSTRUMENTS

PART NUM.	MODEL	DESCRIPTION
5035P2-PXX	VARIOUS	ENCODING ALTIMETER
5934-1A.XX	20K ALT	SEN PRESS ALTIMETER
5934A-1A1.XX	VARIOUS	ALTIMETER
5934A-A69	35K ALT	SEN PRESS ALTIMETER
5934PAD-3AXXX	35K ALT	SEN PRESS ALTIMETER



INVENTORY SUPPORTED MAINTENANCE, REPAIR AND OVERHAUL

[STARTER GENERATORS]

SAFRAN		
PART NUM.	ALT PART NUM.	AIRCRAFT
23032-027	23032-028	Bell 222
23048-016	101-389007-1	KING AIR
23048-018	100-389005-11	BEECH
23064-001	204-060-200-001	BELL
23078-019	23078-019	BEECH 1900
23078-019A		BEECH T-6
23079-000-1	9910292-2	METRO, MERLIN, C-26A, CITATION
23080-050	45AS88801-017	BEECH JET 400A
23081-072		EUROCOPTER
23081-073	23081-073	EUROCOPTER
23085-001	101-369012-11	KING AIR 350
23085-025		PC-12
23088-008	8SC0001	BOMBARDIER DASH 8
23032-SERIES		
23046-007		MU-2
23046-007M		MU-2
23046-028		MU-2
23048-006		CESSNA
23048-012	100-389005-11	KING AIR
23048-015		KING AIR
23048-016	101-389007-1	KING AIR
23048-016H	100-369012-3	KING AIR
23048-018	100-389005-11	KING AIR
23048-SERIES		CESSNA, BEECH
23065-013		CESSNA
23065-013-1		TWIN COMMANDER
23065-018-1		LEAR
23076-001	9912038-2	CESSNA
23076-001-1	9912038-3	CESSNA
23076-004-1		CESSNA
23076-004-1		KING AIR, CITATION
23078-012	9910450-2	CESSNA
23078-019		BEECH 1900, 99
23078-SERIES		BEECH
23079-000-1	90-389001-3	BEECH

AVAILABLE FOR SALE, EXCHANGE OR MRO

STARTER GENERATORS



[STARTER GENERATORS]



150SG122Q
STARTER GENERATOR



23081-XXX
STARTER GENERATOR



418-00051
OIL PRESSURE TRANSMITTER



3567411-1502
FUEL PRESSURE
TRANSMITTER

AVAILABLE FOR SALE, EXCHANGE OR MRO

PART NUM.

ALT PART NUM.

AIRCRAFT

23079-004

9910292-2

CESSNA

23079-009

KING AIR

23079-SERIES

BEECH, TURBO COMMANDER

23080-001-1

9912038-4

CESSNA

23080-003

9914052-9

CITATION

23080-005

CITATION

23080-011

CITATION

23080-012

BEECH

23080-023A

6608458-2

LEARJET

23080-025

9912038-5

CESSNA

APC

PART NUM.

ALT. PART NUM.

AIRCRAFT

150SG-SERIES

200SG-SERIES

CESSNA, PILATUS

250SG-SERIES

BEECH, MU-2

300SG-SERIES

CESSNA, BEECH

[GENERATOR CONTROL UNITS]

PART NUM.

ALT PART NUM.

AIRCRAFT

51509-002

100-384063-1

BEECH

51509-006BR

9912039-3

CESSNA

51530-001

100-384104-1

BEECH

51530-001A

101-364270-1

BEECH

51530-001A

580-379

PIPER

51530-007B

101-364270-5

BEECH

51538-001A

101-364270-5

BEECH

51539-005M

557-124

PIPER

51539-006D

9914050-1

CESSNA

51539-006F

9912039-6

CESSNA

51539-006J

45AS88801-25

BEECH

51539-006M

9910512-1

CESSNA

51539-012N

CESSNA

EXCHANGES ARE AVAILABLE 24/7

[TRANSDUCERS]

PART NUM.	ALT PART NUM.	DESCRIPTION
20-017500	3008	PEDAL POSITION TRANSDUCER
318-01010	50-380108	TORQUE PRESS TRANSMITTER
318-02020		TORQUE PRESS TRANSMITTER
318-100		OIL PRESSURE TRANSMITTER
318-50-D1	50-380108	OIL PRESSURE TRANSMITTER
3268005-0101	489-438	FUEL FLOW TRANSMITTER
3567411-1502	489-482	FUEL PRESSURE TRANSMITTER
3567411-6003	29287-02	TORQUE PRESS TRANSMITTER
3567749-4001	100-389007-1	OIL PRESSURE TRANSMITTER
3567749-6001	489-410	TORQUE PRESS TRANSMITTER
3567749-6001	489-482	TORQUE PRESS TRANSMITTER
3567749-7103	C6SC1084-5	TORQUE PRESS TRANSMITTER
3567749-8001	115-389006	OIL PRESS TRANSMITTER
3567749-9402		OIL PRESS TRANSMITTER
3567749-9502	C6SC1084-3	OIL PRESS TRANSMITTER
3571220-6012		FUEL PRESS INDICATOR
3971046-438	9912019-18	FUEL PRESS TRANSMITTER
418-00044	130-020-3	OIL PRESS TRANSMITTER
418-00051	935A-5002-1	OIL PRESS TRANSMITTER
418-00054	VARIOUS	OIL PRESS TRANSMITTER
418-01064	C6SC1116	OIL PRESS TRANSMITTER
418-02064	VARIOUS	OIL PRESS TRANSMITTER
418-02084	7SC0069	OIL PRESS TRANSMITTER
418-04024	318-02020	TORQUE PRESS TRANSMITTER
418-06064	VARIOUS	TORQUE PRESS TRANSMITTER
418-08014	50-380108	TORQUE PRESS TRANSMITTER
418-09064	7SC0090	TORQUE PRESS TRANSMITTER
418-09084	45AS8625-005	OIL PRESSURE TRANSMITTER
548-550	1/2-2-81-301	FUEL FLOW TRANSMITTER



DH6 418-000-44
OIL PRESSURE
TRANSMITTER



51509
GCU



1013642705
GCU



7SC0123
POSITION TRANSMITTER

AVAILABLE FOR SALE, EXCHANGE OR MRO



Avoid the daily grind.



Call 604.542.8824 or visit us at
precisionaccessories.ca

Avionics
Hydraulics
Accessories
Instruments
Starter Generators

Others sell parts, WE SELL SUPPORT®



Inventory Supported
Maintenance • Repair • Overhaul

[BENZ AIRBORNE TRANSDUCERS]

PART NUM.	ALT PART NUM.	DESCRIPTION
APT-9-100-50GW		BLEED AIR
APTE-2A-2250-85D	130-389002-3	ENGINE TORQUE PRESSURE
APTE-312-1000-200G	101-389023-7	ENGINE OIL PRESSURE
APTE-3-2250-60D	103-380003-3	ENGINE TORQUE PRESSURE
APTE-6KBS-1000-100G	27-19152-1,-3	FUEL PRESSURE
APTE-6KBS-1000-200G	27-19153-1,-3	ENGINE OIL PRESSURE
APTE-6KBS-1000-3000A	27-19154-1,-3	HYDRAULIC OIL PRESSURE
APTE-7KBS-1000-3000A	27-19155-1,-3	OXYGEN PRESSURE
ATPE-7KBS-1500-200G	101-389023-X	ENGINE OIL PRESSURE
IPT-20RTP-1000-150G	975-21-15-209	GEAR BOX OIL PRESSURE
IPT-20RTPE-1000-200G-1	975-21-15-214	ENGINE OIL PRESSURE
IPT-51DF-1000-70D	975-21-15-206	MAIN OIL PRESSURE
IPTE-155-1000-200D	AC-710011-A00	ENGINE OIL PRESSURE
IPTE-26F-1000-250G	AC-710011-A00	ENGINE OIL PRESSURE
IPTE-26S-1000-250G	AC-710011-A00	ENGINE OIL PRESSURE
IPTE-27-1000-4000SG	110019	HYDRAULIC OIL PRESSURE
IPTE-51F-1000-70D	PS 50153-2	ENGINE TORQUE PRESSURE

[WHEELS & BRAKES]

PART NUM.	ALT PART NUM.	DESCRIPTION
030-15000	30-150	BRAKE ASSEMBLY
030-1890X	30-189X	BRAKE ASSEMBLY
040-23901		WHEEL ASSEMBLY
100-380011-1	2-1573	BRAKE ASSEMBLY
101-8001-X	2-1301	BRAKE ASSEMBLY
115-8001-3	2-1138	BRAKE ASSEMBLY
2-1174-1		BRAKE ASSEMBLY
2-1203-X		BRAKE ASSEMBLY
2-1329-3		BRAKE ASSEMBLY
2-1435-2	551-740	BRAKE ASSEMBLY
2-1445-1		BRAKE ASSEMBLY
2-1466-3/4		BRAKE ASSEMBLY
2-1479-1		BRAKE ASSEMBLY



APTE-312-1000-200G
ENGINE OIL PRESSURE



2-1565
MAIN BRAKE ASSEMBLY



2-1528-6
BRAKE ASSEMBLY



030-1890-2
BRAKE ASSEMBLY

AVAILABLE FOR SALE, EXCHANGE OR MRO

[WHEELS & BRAKES]

WHEEL & BRAKES

AVAILABLE FOR SALE, EXCHANGE OR MRO

PART NUM.	ALT PART NUM.	DESCRIPTION
2-1466-3/4		BRAKE ASSEMBLY
2-1479-1		BRAKE ASSEMBLY
2-1502-3	9914136-9	BRAKE ASSEMBLY
2-1517		BRAKE ASSEMBLY
2-1517-X		BRAKE ASSEMBLY
2-1522-1	2-1522-1	BRAKE ASSEMBLY
2-1528-6	9912246-27	BRAKE ASSEMBLY
2-1529-X	9912222-1X	MAIN BRAKE ASSEMBLY
2-1530-4	9912246-28	BRAKE ASSEMBLY
2-1565	2-1565	BRAKE ASSEMBLY
2-1574		MAIN BRAKE ASSEMBLY
2-1576	101-380096-1	BRAKE ASSEMBLY
2-1580		MAIN BRAKE ASSEMBLY
2-1585		BRAKE ASSEMBLY
2-1599		BRAKE ASSEMBLY
2-1656	9912561-3	MAIN BRAKE ASSEMBLY
2-1661		BRAKE ASSEMBLY
2-1674-1		BRAKE ASSEMBLY
30-106	551-729	BRAKE ASSEMBLY
30-142	551-745	BRAKE ASSEMBLY
30-146	030-14600	BRAKE ASSEMBLY
30-162	030-16200	MAIN BRAKE ASSEMBLY
30-204A	030-20401	BRAKE ASSEMBLY
3-1208-1	50-300010-133	MAIN WHEEL ASSEMBLY
3-1283		MAIN WHEEL ASSEMBLY
3-1341-1	01-8001-47	MAIN WHEEL ASSEMBLY
3-1418	9914069-2	NOSE WHEEL ASSEMBLY
3-1442		NOSE WHEEL ASSEMBLY
3-1481	101-8026-5	NOSE WHEEL ASSEMBLY
3-1490-1	9912222-11	MAIN WHEEL ASSEMBLY
3-1548-1		WHEEL ASSEMBLY
5002116		BRAKE ASSEMBLY
5002376	551-720	BRAKE ASSEMBLY
5003096-4	6600330-7	BRAKE ASSEMBLY
5003096-6	5003096-6	BRAKE ASSEMBLY

Others sell parts, **WE SELL SUPPORT®**

PART NUM.	ALT PART NUM.	DESCRIPTION
5003096-7	6600330-21	BRAKE ASSY
5004190-6	45AS38202-017	BRAKE ASSEMBLY
5006749-5	114-388024-1	BRAKE ASSEMBLY
5007397-1		MAIN WHEEL ASSEMBLY
9550273		BRAKE ASSEMBLY

[TACH GENERATORS]

PART NUM.	AIRCRAFT	DESCRIPTION
3010820	P&W	TACH GENERATOR
0850350-X	CESSNA	TACH GENERATOR
102-389015-5	BEECH	TACH GENERATOR
45AS86823-001	BEECH	TACH GENERATOR
462-105	PIPER	TACH GENERATOR
462-106	PIPER	TACH GENERATOR
50196-000	PIPER	TACH GENERATOR
50-389040	BEECH	TACH GENERATOR
50-389057-1	BEECH	TACH GENERATOR
850287-1	COMMANDER	TACH GENERATOR
96-389000-3	BEECH	TACH GENERATOR
9910378-X	CESSNA	TACH GENERATOR
9912034-1	CESSNA	TACH GENERATOR
A5278110302	KOLLSMAN	TACH GENERATOR
AG34	TASK	TACH GENERATOR
AN5547-2	GENERIC	TACH GENERATOR
EM8000	ELECTRO-MECH	TACH GENERATOR



3-1490-1
MAIN WHEEL ASSEMBLY



5006749-5
BRAKE ASSEMBLY




50-389057-1
TACH GENERATOR



9910378-2
TACH GENERATOR

AVAILABLE FOR SALE, EXCHANGE OR MRO

PRECISION STARTER GENERATORS



*Over 40,000 generators
serviced in the past 15 years*

*Most models serviced from all
major manufacturers*

Quick turnaround on overhauls

AVAILABILITY

Over 700 LRU's available to ship
within 30 minutes

QUALITY

Airline and Fleet Operators demand
our kind of diligence

FLEXIBILITY

Sales, repairs, exchanges & overhauls
as you need them



Inventory Supported
Maintenance • Repair • Overhaul

**NO AOG FEE
ALWAYS AVAILABLE**

**404.218.5777
WORLDWIDE**

Others
sell parts,
**WE SELL
SUPPORT**

PARTIAL LISTING OF CAPABILITIES AND PARTS: FOR MORE INFORMATION VISIT
WWW.PRECISIONAVIATIONGROUP.COM OR CALL 404.767.5800.

[FUEL PUMPS]

PART NUM.	ALT PART NUM.	AIRCRAFT
1296-00-1NV	1296-00-1	PIPER
1C12-1	50-389094-5	BEECH
1C12-17	9910288-8	CESSNA
1C12-3	035A948426-1	MU-2
1C15-4	481-788	PIPER
1C27-18	118-389006-5	BEECH
1C54-1	481-844	PIPER
1C64-5	118-389006-5	BEECH
1C6-9	48812-00	GULFSTREAM COMMANDER
1C7-12	9912017-3	CESSNA
1C7-15	45AS48015-2	BEECH
1C7-9	45AS48015-3	BEECH
1D2-12	50-380177-5	BEECH
1D2-13	50-380177-7	BEECH
1D2-6	50-380177-1	BEECH
1D3-4	630309-503	GULFSTREAM COMMANDER
2B6-63	481-802	PIPER
2B6-64	481-801	PIPER
2B7-29	9910202-4	CESSNA
2C6-SERIES	VARIOUS PIPER	PIPER
3B7-4	630390-503	GULFSTREAM COMMANDER
4140-00-15	C291504-0201	CESSNA
4140-00-153	VARIOUS CESSNA	CESSNA
4140-00-39NV	4140-00-39	PIPER
RG34720A	481-824	PIPER
RG34720A	91-380003-3	BEECH
RG52400D	50595-04	GULFSTREAM COMMANDER

AVAILABLE FOR SALE, EXCHANGE OR MRO



1C12-1
PIPER FUEL PUMP



1C6-9
FUEL PUMP



1D3-4
GULFSTREAM FUEL PUMP



1C12-3
MU-2 FUEL BOOST PUMP



INVENTORY SUPPORTED MAINTENANCE, REPAIR AND OVERHAUL

[VACUUM PUMPS]



2C27-1
FUEL PUMP



WF328893
FILTER ELEMENT



WF335819
HYD OIL FILTER



1C27-10
FUEL PUMP CARTRIDGE

AVAILABLE FOR SALE, EXCHANGE OR MRO

PART NUM.

AIRCRAFT

211CC	VARIOUS
212CC	VARIOUS
215CC	BEECH, CESSNA, GULF COMMANDER, PIPER
216CW	BEECH, CESSNA, GULF COMMANDER, PIPER
242CW	BEECH CESSNA
441CC	CESSNA
441CC-17	PIPER
441CC-3	CESSNA
441CC-7	GULF COMMANDER, PIPER
441CC-9	PIPER
442CW	CESSNA
442CW-12	BEECH
442CW-14	BEECH
442CW-20	BEECH
442CW-4	CESSNA
442CW-6	CESSNA
442CW-8	CESSNA

[DONALDSON FILTERS]

PART NUM.

DESCRIPTION

3034292WFC	OIL FILTER ELEMENT
3034393WFC	OIL FILTER ELEMENT
3034507WFC	CLEANABLE OIL FILTER ELEMENT
3035101WFC	OIL FILTER ELEMENT
334500WFC	OIL FILTER ELEMENT
334508WFC	OIL FILTER ELEMENT
334521WFC	FUEL NOZZLE SCREEN
P-1105	FUEL NOZZLE SHEATH
PT6	
TPE331	
WF325928	FILTER ELEMENT
WF326058	FILTER ELEMENT
WF328893	FILTER ELEMENT

[ACCESSORIES]


PART NUM.	ALT PART NUM.	DESCRIPTION
100-524073-1	EM508-1000	FLAP DRIVE MOTOR & G/BOX ASSY
100-9022-13	133-380070-13	LANDING GEAR CONTROL ASSY
101-384025-23		WINDSHIELD LH
101-384025-24		WINDSHIELD RH
103648-13		OUTFLOW VALVE
103648-18		OUTFLOW VALVE
103648-4		OUTFLOW VALVE
103648-7	103648-7	OUTFLOW VALVE
117-389012-1	93880-18	ENGINE MOUNT
130346-12	130346-12	CABIN PRESSURE CONTROLLER
1520T100-109	101-380013-13	FLOWPACK
1532-10C	101-384144-3	DISTRIBUTION VALVE
1532-3C	101-384144-1	DISTRIBUTION VALVE
176401-77	101-384207-5	OXYGEN CYL & REGULATOR ASSY
1H75-12	101-380027-3	REGULATOR & RELIEF VALVE ASSY
1H98-2	101-380025-21	FLOW CONTROL VALVE
30-215-8	473275	FIRE DETECTOR
30E20-97A		GENERATOR, DC
3701-14	101-380005-33	LIFT TRANSDUCER
37100-4	101-388009-5	ACCUMULATOR
4402-2	101-384032-7	SHUTOFF OXYGEN VALVE
4711-16	101-381012-7	VALVE ASSY
4712-2	101-381015-3	BLEED AIR VALVE ASSEMBLY
4712-21		FUEL SYSTEM SHUTOFF VALVE
501-1228-04	PS-835D	EMERGENCY POWER SUPPLY
501-1712-02	PS-855B	EMERGENCY POWER SUPPLY
A4503M9-5	A4503M9-5	LANDING GEAR HANDLE
AA-34-12M1	45AS61014-107	TRIM ACTUATOR
AA-35-2M1	45AS88830-007	ACTUATOR
BYLB-50474-1	99-380010-1	BUTTERFLY VALVE ASSEMBLY
EM424-8	101-389025-5	FUEL SHUTOFF VALVE
EM450-4	114-389039-21	ICE VANE ACTUATOR
EM450-5	114-389039-23	ICE VANE ACTUATOR ASSEMBLY
EM603-7	101-384135-3	BLOWER ASSEMBLY
EM603-9	90-384031-1	BLOWER ASSEMBLY
EM609-3	101-384004-5	BLOWER ASSEMBLY
EM640-1	101-384176-1	BLOWER ASSEMBLY

AVAILABLE FOR SALE, EXCHANGE OR MRO

ACCESSORIES



EXCHANGES ARE AVAILABLE 24/7




Hard to find parts are easy
when you know where to look.

PAL 
PRECISION ACCESSORIES
& INSTRUMENTS AUSTRALIA
A **PAG** Company

Call 617.3198.3660 or visit us at
precisionaccessories.com.au

Avionics
Hydraulics
Instruments
Wheels & Brakes
Starter Generators

Others sell parts, WE SELL SUPPORT®



Inventory Supported
Maintenance • Repair • Overhaul

[ACCESSORIES]

PART NUM.	ALT PART NUM.	DESCRIPTION
EM609-3	101-384004-5	BLOWER ASSEMBLY
EM640-1	101-384176-1	BLOWER ASSEMBLY
F7-51-3	101-380025-11	ELECTRONIC CONTROLLER
F7-51-5	101-380025-17	ELECTRONIC CONTROLLER
NYLC50427	50-554341-59	ELECTRO MECHANICAL ACTUATOR

[ENGINE ACCESSORIES]

PART NUM.	DESCRIPTION
024800-101 SERIES	HIGH PRESSURE FUEL PUMP
025323-101-SERIES	HIGH PRESSURE FUEL PUMP
025323-150	HIGH PRESSURE FUEL PUMP
025323-300-SERIES	HIGH PRESSURE FUEL PUMP
025323-402-SERIES	HIGH PRESSURE FUEL PUMP
025323-500-SERIES	HIGH PRESSURE FUEL PUMP
10-381550-SERIES	IGNITION EXCITERS
10552-SERIES	FUEL TO OIL HEATERS
10588-SERIES	FUEL TO OIL HEATERS
10728A	FUEL TO OIL HEATERS
11011563	START FLOW CONTROLS
11011564	START FLOW CONTROLS
23912-5	AUTOMATIC DUMP VALVE
24056-SERIES	AUTOMATIC DUMP VALVES
24500	START FLOW CONTROLS
25094	START FLOW CONTROLS
25096	START FLOW CONTROLS
25098	START FLOW CONTROLS
25232	START FLOW CONTROLS
252324-SERIES	START FLOW CONTROLS
2524195-1	TEMP COMPENSATOR
2524196	FUEL CONTROL
2524245-3	FUEL CONTROL
2524259-SERIES	FUEL CONTROL
2524281-1	FUEL CONTROL
2524288	FUEL CONTROL
2524299	FUEL CONTROL



F7-51-5
ELECTRONIC CONTROLLER



10-381550-4
IGNITION EXCITER



25323-300-3
HIGH PRESSURE
FUEL PUMP



7000622-901
DASH-8 VERTICAL GYRO


AVAILABLE FOR SALE, EXCHANGE OR MRO

[ENGINE ACCESSORIES]

AVAILABLE FOR SALE, EXCHANGE OR MRO



90-384031-1
BLOWER ASSEMBLY



25234
START FLOW CONTROL



2524440-SERIES
FLOW CONTROL UNIT



32444707-SERIES
TORQUE LIMITER

PART NUM.	DESCRIPTION
2524288	FUEL CONTROL
2524299	FUEL CONTROL
2524314,15,16-SERIES	FUEL CONTROL
2524439,40-SERIES	FUEL CONTROL
2524681-1	TEMP COMPENSATOR
25317	FLOW DIVIDER
25336-SERIES	FLOW DIVIDER
25638-SERIES	FLOW DIVIDER
25672	START FLOW CONTROLS
25920-SERIES	FLOW DIVIDER
26035-SERIES	FLOW DIVIDER
26130-SERIES	FLOW DIVIDER
26230-SERIES	FLOW DIVIDER
26380	FLOW DIVIDER
26425-1	FLOW DIVIDER
26495-SERIES	FLOW DIVIDER
26515-01	FLOW DIVIDER
26550-01	FLOW DIVIDER
26560-01	FLOW DIVIDER
3026503	BYPASS VALVE
3038242	BYPASS VALVE
3244723,38,45,46,-SERIES	FUEL CONTROL
3244752,53,55,-SERIES	FUEL CONTROL
3244764,68,69-SERIES	FUEL CONTROL
3244770,71,73,75,77-SERIES	FUEL CONTROL
3244786,87,99,89,99-SERIES	FUEL CONTROL
3244801-1	FLOW DIVIDER
3244802-3	FUEL CONTROL
3244809,31,34,56,72,97-SERIES	FUEL CONTROL
386101-5	HIGH PRESSURE FUEL PUMP
399701-SERIES	HIGH PRESSURE FUEL PUMP
4138XXX-SERIES	FUEL CONTROL
702801-5	HIGH PRESSURE FUEL PUMP
825601-5	HIGH PRESSURE FUEL PUMP
83311-49930-SERIES	IGNITION EXCITERS
8426-SERIES	FUEL TO OIL HEATERS
RG15980L-SERIES	BOOST PUMPS

INVENTORY LOCATIONS: ATL / KFFC / LFT / IDP / LAX / BNE / YVR / GRU / SIN

[KING AIR]

PART NUM.	ALT PART NUM.	DESCRIPTION
025323-101-XX		ENGINE FUEL PUMP
025323-300-03	3031708	FUEL PUMP PT6
025323-300-03	3031708	ENGINE FUEL PUMP
064-1016-00	KCU-951	HIGH FREQUENCY CONTROLLER
066-3046-07	KI-525A	HORIZONTAL SITUATION INDICATOR
10010A	115-384002-9	HEAT EXCHANGER
100-364217-XX		PCB ANNUN FAULT DETECT
100-380006-XX	267-901-00X	FUEL QUANTITY INDICATORS
100-384049-1	ST-502J	TORQUE PRESSURE TRANSMITTER
100-384063-1	51509-002R	GENERATOR CONTROL
100-384072-5	26501-2	AC COMPRESSOR MOTOR
100-384081-1	SRL-C8C	PERCENT TORQUE INDICATOR
100-384093-3		FLAP POSITION INDICATOR
100-384095-1	570-524	VOLT-FREQUENCY INDICATOR
100-384118-XX	30-1329-3M	STROBE LIGHT
100-384118-XX	30-1329-3XX	NAV POSITION LIGHT ASSEMBLY
100-389005-11	23048-018	DC STARTER GENERATOR
100-389015-1	10021A	OIL COOLER
100-389021-1	ST-502M	TORQUE PRESSURE TRANSMITTER
100-524073-1	EM508-1000	FLAP DRIVE MOTOR & G/BOX ASSY
100-524074-1		FLAP MOTOR
101-340459-X		PCB RELAY MODULE
101-364092-XX		PCB TIME DELAY
101-364210-XX		PCB BATT CHARGE MONITOR
101-364270-1	51530-001A	GENERATOR CONTROL
101-364270-5	51530-007B	GENERATOR CONTROL
101-364572-XX		PCB ICE VANE
101-364580-XX		PCB FAULT DETECTION
101-364582-XX		PCB ADVISORY LITE TEST
101-364584-XX		PCB BATT CHARGE MONITOR
101-380005-XX	3601-X	COMPUTERS
101-380012-5	230-1	DIMMER CONTROL
101-380012-X	VARIOUS	5 VOLT DIMMER
101-380013-13	1520T100-109	FLOW PACK
101-380013-3	1520T100-10	PNEUMOSTAT




064-1016-00
HIGH FREQUENCY
CONTROLLER



066-3046-07
HORIZONTAL SITUATION
INDICATOR



51509-002R
GENERATOR CONTROL



23048-016
STARTER GENERATOR

AVAILABLE FOR SALE, EXCHANGE OR MRO

KING AIR WINDSHIELDS & INSTALLATION KIT

Authorized Distributors



Inventory Supported
Maintenance • Repair • Overhaul

36-Month Warranty

**OEM Certified King Air
Windshield Manufacturer**

Latest OEM Approved Design

**Same Materials & Components
as New OEM Parts**

WINDSHIELD INSTALLATION KIT

101-5041-35



KING AIR - OVH/REBUILT

101-384025-23 Windshield (LH)

101-384025-24 Windshield (RH)

BEECH 1900 - REBUILT

114-384020-5 Windshield Assembly (LH)

114-384020-6 Windshield Assembly (RH)

**NO AOG FEE
ALWAYS AVAILABLE**

**404.218.5777
WORLDWIDE**

Others
sell parts,
**WE SELL
SUPPORT**

[KING AIR]

PART NUM.	ALT PART NUM.	DESCRIPTION
101-380025-21	1H98-2	FLOW CONTROL VALVE
101-380025-XX	F7-51-X	ELECTRONIC CONTROLS
101-380030-9	056-0020-02	TURN & SLIP
101-380032-3	20B380-4	TURN AND BANK INDICATOR
101-380033-1	30040-1175	IVSI
101-380068-5	1535-05	MAX ALLOW AIRSPEED
101-380091-3	43-201-1	TORQUE INDICATOR
101-380096-1	2-1576	BRAKE ASSEMBLY
101-381000-9	4706-24	BLEED AIR SHUTOFF VALVES
101-381011-X	4706-X	BLEED AIR SHUTOFF VALVES
101-384003-7	10009A	COIL
101-384004-1	M7921C-2B	VANAXIAL FAN
101-384004-13	EM609-6	BLOWER ASSEMBLY
101-384004-5	EM609-3	BLOWER ASSEMBLY
101-384008-3	SR-2AM	TORQUE PRESSURE INDICATOR
101-384024-1	8544206	VAPORATOR COIL
101-384025-23		WINDSHIELD LH
101-384025-24		WINDSHIELD RH
101-384029-1	558-1	FLAP POSITION INDICATOR
101-384032-1	4401-1	FUEL VALVE
101-384074-XX	VARIOUS	AIRSPEEDS
101-384101-XX	VARIOUS	AIRSPEEDS
101-384106-X		DC LOADMETER
101-384107-X	VARIOUS	VOLT-FREQUENCY INDICATORS
101-384122-X	VARIOUS	OIL TEMP/OIL PRESS
101-384137-5		LANDING GEAR SWITCH
101-384137-7	A4503M122-7	LANDING GEAR SWITCH ASSEMBLY
101-384144-1	1532-3C	DEICE DISTRIBUTION VALVE
101-384154-3	522686	ITT INDICATOR
101-384157-5	100-0051-03	PROP TACH INDICATOR
101-384159-7	100-0049-03	PERCENT TACH INDICATOR
101-384176-X	VARIOUS	VENTILATING BLOWER ASSEMBLY
101-384177-X	EM2091-X	SPEED CONTROLLER
101-384186-3	SRL-C2F	PERCENT TORQUE INDICATOR
101-384189-X		FUEL QUANTITY INDICATORS

AVAILABLE FOR SALE, EXCHANGE OR MRO

BEECH KING AIR



[KING AIR]



10-381550-4
IGNITION EXCITER



501-1228-04
POWER SUPPLY



101-389007-1
DC STARTER
GENERATOR



3-1341-1
WHEEL ASSEMBLY

AVAILABLE FOR SALE, EXCHANGE OR MRO

PART NUM.	ALT PART NUM.	DESCRIPTION
101-384222-5	MD118-5	PROP AMMETER
101-388005-17	HP50A-1	HYDRAULIC POWER PACK
101-388009-5	37100-4	ACCUMULATOR
101-388014-X	45600-X	ACTUATORS
101-389005-3	ST-502K-1	OIL PRESSURE TRANSMITTER
101-389006-11	EM418	ACTUATOR ASSEMBLY
101-389006-7	SYLC50298-3	LINEAR ACTUATOR
101-389007-1	23048-016	DC STARTER GENERATOR
101-389022-X	MD116-X	PROP-AMMETERS
101-389025-3	EM424-X	FUEL SHUT-OFF VALVE
101-389042-5	86-104-3	FUEL FLOW TRANSMITTER
101-389044-3	ST-502N-1	PRESSURE TRANSMITTER
101-500053-X	509-0001-9XX	TURN & SLIP
101-521016-1,-2	129-521050-1 ,-2	FLAP ACTUATOR
101-8001-47	3-1341-1	WHEEL ASSEMBLY
101-8001-91	101-380096-1	BRAKE ASSEMBLY
101-8002-3	5002256	WHEEL ASSEMBLY
101-8027-3P		ALUMINUM NOSE WHEEL
101-810000-651		LH MAIN GEAR ASSEMBLY
101-810000-652		RH MAIN GEAR ASSEMBLY
101-810009-9	101-810002	HIGH FLOAT MAIN GEAR
101-810010-5		MAIN GEAR ASSEMBLY
101-810082-1	101-810158-1	300/350 MAIN GEAR
101-810091-7,-9		DRAG LEG ASSEMBLY
102-364031-1	40-0127-1	ROTATING BEACON
102-380011-XX	VARIOUS	TACH INDICATORS
102-380014-X	MD63-X	OIL TEMP-PRESS INDICATORS
103310-X		OUTFLOW VALVES
103460-X	50-554230-97	OUTFLOW VALVES
103570-X		OUTFLOW VALVES
103598-X		OUTFLOW VALVES
103648-X		OUTFLOW VALVES
10-381550-1		IGNITION EXCITER
10-381550-4	3035889	IGNITION EXCITER
105-389011-XX	MD105-XX	MODULES



INVENTORY SUPPORTED MAINTENANCE, REPAIR AND OVERHAUL

PART NUM.	ALT PART NUM.	DESCRIPTION
10585K	3057249-01	FUEL HEATER
108-384003-23	MD108-11	ENGINE CLUSTER
109-384000-1	MD123-1	VOLT INDICATOR
109-384001-1	MD117-1	LOAD INDICATOR
109-389002-7	EM424-4	FUEL SHUT-OFF VALVE
109-389002-9	EM424-9	FUEL SHUT-OFF VALVE
114-389039-XX	EM450-X	ICE VANE ACTUATORS
115-380111-19	1136T100-19	HORIZONTAL STABILIZER ACTUATOR
115-384001-X		CONDENSOR BLOWER
115-384002-9	10010A	HEAT EXCHANGER
115-384014-3	25122-C84C-2-A3	TORQUEMETER
115-389014-5	210631	OVERSPEED GOVERNOR
115-8001-3	2-1138	BRAKE ASSEMBLY
115-811020-613		GEAR BOX & MOTOR ASSEMBLY
117-384014-X	100-0049-0X	TACHOMETER INDICATOR
117-384019-3		FUEL QUANTITY INDICATORS
117-389012-1	93880-18	ENGINE MOUNT
122-382015-11	501-1412-03	ATTITUDE GYRO
128-380079-X	MD142-X	VOLT-AMMETERS
128-384045-5	55007-005	TURBINE RPM INDICATOR
128-384046-3	55007-004	FAN RPM INDICATOR
130346-12	130346-12	CABIN PRESSURE CONTROLLER
130374-XX		PRESSURIZATION CONTROLLERS
130-380005-X	201530-113XX	AIRSPEEDS
130-380039-3	20130-11341	MAX ALLOW AIRSPEED
130-380041-X	VARIOUS	ITT INDICATORS
130-380042-X	VARIOUS	TORQUE INDICATORS
130-380043-X	VARIOUS	PROP TACHS
130-380044-X	VARIOUS	TURBINE TACH INDICATORS
130-380045-X	VARIOUS	OIL PRESS/OIL TEMP
130-389002-3	130-389002-1	TORQUE TRANSMITTER
150-906-002	90-380009-7	FUEL FLOW TRANSMITTER
1520T100-109	101-380013-13	FLOWPACK
1532-10C	101-384144-3	DISTRIBUTION VALVE
1532-3C	101-384144-1	DISTRIBUTION VALVE



101-8001-91
BRAKE ASSEMBLY



128-384045-5
RPM INDICATOR



130-38005-7
AIRSPEED INDICATOR



130374
PRESSURIZATION
CONTROLLER

AVAILABLE FOR SALE, EXCHANGE OR MRO

In the right hands, it will start a revolution.




PAT
PRECISION AERO TECHNOLOGY
A **PAG** Company

Call 562.595.6055 or visit us at
precisionaerotechnology.com

Avionics
Hydraulics
Accessories
Instruments
Wheels & Brakes

Others sell parts, WE SELL SUPPORT®



Inventory Supported
Maintenance • Repair • Overhaul

[KING AIR]

PART NUM.	ALT PART NUM.	DESCRIPTION
176401-77	101-384207-5	OXYGEN CYL & REGULATOR ASSY
1C12-1	50-389094-5	BOOST PUMP
1D2-12	50-380177-5	BOOST PUMP
1H75-12	101-380027-3	REGULATOR & RELIEF VALVE ASSY
1H98-2	101-380025-21	FLOW CONTROL VALVE
1U367-207-8	101-380036-1	ATTITUDE GYRO
1U367-232-2	101-380036-1	ATTITUDE GYRO
210638	101-389000-5	PROP GOVERNOR
213100	5485-006	PROP SYNCH ACTUATOR
2-1576	101-380096-1	MAIN BRAKE ASSEMBLY
23048-016	101-389007-1	STARTER GENERATOR
23085-001	101-369012-11	STARTER GENERATOR
3002-J71	C6SC1005-5	CABIN ALTITUDE DIFF/PRESS IND
30-0467-1 OR -5		STROBE LIGHT
30-162	030-16200	MAIN BRAKE ASSEMBLY
3019109	SFC112,113	START VALVE
3019906	25536-4	FLOW DIVIDER
30301102		FIRE BOTTLE ASSEMBLY
3033808	399701-5	ENGINE FUEL PUMP
30400018-1		FIRE BOTTLE ASSEMBLY
3100922-05		BLEED VALVE
3100923-02		BLEED VALVE
3-1208-1 OPT 1	50-300010-133	MAIN WHEEL ASSEMBLY
3-1341-1	101-8001-47	MAIN WHEEL ASSEMBLY
3244707-X		TORQUE LIMITER
3244745-X	PW3027049C	FUEL CONTROLS
3244755-X		FUEL CONTROLS
3244801-1	26035-1	FLOW DIVIDER
33-524023-XX		TRIM ACTUATOR
35-364151-XX		FLAP MOTORS
36-920001-603	2B7-34	FUEL BOOST PUMP
3701-14	101-380005-33	LIFT TRANSDUCER
3701-2	101-380005-9	LIFT TRANSDUCER
37100-4	101-388009-5	ACCUMULATOR
394230-X-X		FUEL SHUTOFF VALVES
3E1150-XX		DEICE TIMER
40-0100-XX		ANTI COLLISION LIGHT

AVAILABLE FOR SALE, EXCHANGE OR MRO



30301102
FIRE BOTTLE ASSEMBLY



RT-220
RADIO ALTIMETER RECEIVER



1C12-1
BOOST PUMP



3-1341-1
MAIN WHEEL ASSEMBLY

AVAILABLE FOR SALE, EXCHANGE OR MRO



76-174-1
FUEL PROBE



8210-024-01
PROP GOVERNOR



90-3844031-1
BLOWER ASSEMBLY



50-389095
FUEL SHUTOFF VALVE

PART NUM.	ALT PART NUM.	DESCRIPTION
50-820004-3		SHIMMY DAMPER
50-820208-5		NOSE GEAR ACTUATOR
51538-001A	101-364270-5	GENERATOR CONTROL UNIT
5485-066		PROP SYNCH ACTUATOR
55-554341-51	NYLC9871	BYPASS VALVE ACTUATOR
55-554341-59	NYLC50427	BYPASS VALVE
559-1	AN5786-1	FLAP POSITION TRANSMITTER
60-1321-1,-7		POWER SUPPLY
60-1750-X	701571	STROBE POWER SUPPLY
60-2799-1		STROBE POWER SUPPLY
60-3157-1		POWER SUPPLY
60-384002-X	C241-500-XX	CABIN BLOWERS
6852-920	213499	PROP SYNCHROPHASER
7000622-901	VG-14A	VERTICAL GYRO
7004126-901	FZ-400	FLIGHT GUIDANCE COMPUTER
76-174-1	100-380006-167	FUEL PROBE
795-X		LIFT TRANSDUCERS
801292-01		OXYGEN REGULATOR
81-101-3	101-384151-5	FUEL QUANTITY INDICATOR
8210-007-01	8210-007G	GOVERNOR
8210-024-01	3035931	PROP GOV
8210-310	8210-310	PROP GOVERNOR
8210-XXX		PROP GOVERNORS
86400-1199	86400-1199	CLOCK
90-380009-7	150-906-002	FUEL FLOW TRANSMITTER
90-380009-X	267-917-XXX	FUEL FLOW INDICATORS
90-380028-X	20126-XXXXX	MAX ALLOW AIRSPEED
90-380037-X	VARIOUS	FUEL FLOW INDICATORS
90-380038-1	2-1574	BRAKE ASSEMBLY
90-384026-XX	52194X	ITT INDICATOR
90-384028-5	100-0034-08	TACHOMETER
90-384031-1	EM603-9	BLOWER ASSEMBLY
90-389001-3	23079-000-1	STARTER GENERATOR
90-810040-1		DRAG BRACE ASSEMBLY
9133-81-C1		FUEL FLOW TRANSMITTER
9133-84-B1		FUEL FLOW TRANSMITTER
91-380002-3	40-1	LANDING GEAR MOTOR

PART NUM.	ALT PART NUM.	DESCRIPTION
9133-84-B1		FUEL FLOW TRANSMITTER
91-380002-3	40-1	LANDING GEAR MOTOR
91-380003-3	RG34720A	ENGINE DRIVEN AUX PUMP
91-380012-3	SR-2AG	TORQUE PRESSURE INDICATOR
91-810010-5		GEAR BOX & MOTOR ASSEMBLY
935A-5002-001	418-00051	PRESSURE TRANSMITTER
96-380030-1	210662	PROP GOVERNOR
96-384056-X	6121-X	MANIFOLD PRESS INDICATORS
96-384057-X	511L-4-XX	DUAL TACHS
96-384058-11		ENGINE GAUGE 3 IN 1
96-384061-X		DE-ICE PRESSURE GAUGES
96-389000-3	H60-050	TACH GENERATORS
965-0476-088		GROUND PROX WARN SYSTEM
973347	PV3-011-17	HYDRAULIC PUMP
97-380000-33	1520T100-115	FLOW PACK
97-820000-613	101-8021-5P	NOSE GEAR ASSEMBLY
99-524025-7	EM404	FLAP MOTOR & GEARBOX
99-8003	9544397-1	BRAKE ASSEMBLY
99-810057-651		MAIN GEAR ACTUATOR
99-810057-652		MAIN GEAR ACTUATOR
A4503M9		LANDING GEAR HANDLE
A4503M9-5	A4503M9-5	LANDING GEAR HANDLE
AA-35-2M1	45AS88830-007	ACTUATOR
AI-804CJ	501-1197-32	GYRO HORIZON
AI-804NF	501-1296-04	ATTITUDE GYRO
APTE-7KBS-1500-200G	101-389023-5	ENGINE OIL PRESS TRANSDUCER
B210631	101-389029-3	OVERSPEED GOVERNOR
BA-141	4016341-905	SERVO ALTIMETER
BYLB-50474-1	99-380010-1	BUTTERFLY VALVE ASSEMBLY
BYLF50290	97-55012-3	TEMP SENSOR
CM1000-33	90-380001-33	MASTER CYLINDER
EM2081-13A	114-389040-21	SENSOR
EM424-8	101-389025-5	FUEL SHUTOFF VALVE
EM450-4	114-389039-21	ICE VANE ACTUATOR
EM450-5	114-389039-23	ICE VANE ACTUATOR ASSEMBLY

AVAILABLE FOR SALE, EXCHANGE OR MRO



90-384031-1 EM609
BLOWER ASSEMBLY



99-810057-651
BEECHCRAFT
MAIN LANDING ASSY



101-384004
BLOWER ASSEMBLY



10-381550-4
IGNITION BOX



1520T100-109
FLOWPACK



90-380038-1
BRAKE ASSEMBLY



90-380009-7
FUEL FLOW XMITER



114-389039-23
ICE VALVE ACTUATORS

AVAILABLE FOR SALE, EXCHANGE OR MRO

PART NUM.	ALT PART NUM.	DESCRIPTION
EM603-7	101-384135-3	BLOWER ASSEMBLY
EM603-9	90-384031-1	BLOWER ASSEMBLY
EM609-3	101-384004-5	BLOWER ASSEMBLY
EM640-1	101-384176-1	BLOWER ASSEMBLY
EM8001	50-389057-1	TACH GENERATOR
EM9018-1	EM9018-1	AIR VALVE
F7-51-3	101-380025-11	ELECTRONIC CONTROLLER
F7-51-5	101-380025-17	ELECTRONIC CONTROLLER
HYLZ 50336-1	HYLZ50336-1	TEMPERATURE CONTROLLER
HYLZ50336-1		TEMP CONTROLLER
M2620B	50-380116	BLOWER MOTOR
MC815AS-1		LANDING GEAR CONTROL
MD106-9	101-384106-9	VOLT LOAD METER
NYLC50427	50-554341-59	BYPASS VALVE ACTUATOR
NYLC9871	NYLC9871	ACTUATOR
PC-17 SERIES		STATIC INVERTER
ST-502H-1	99-389014-3	TORQUE PRESSURE TRANSMITTER
AA-34-12M1	45AS61014-107	TRIM ACTUATOR
APTE-2A-2250-85D	130-389002-3	ENG TORQUE PRESS TRANSMITTER
EM4132-2	133-380027-11	LINEAR ACTUATOR
EM6003-1	133-380068-1	BLOWER, VANE AXIAL
PC-450 SERIES		STATIC INVERTER

PART NUM.	ALT PART NUM.	DESCRIPTION
064-01076-0101	KTR 909B	RADIO RECEIVER-TRANSMITTER
066-01143-0201	MST-67A	TRANSPONDER
066-04028-1001	RMU-556	RADIO MANAGEMENT UNIT
066-04028-1002	RMU-556	RADIO MANAGEMENT UNIT
066-04029-0102	KDA-557	DATA ADAPTER
066-50024-1030	066-50024-10-30	FPD 500 FLAT PANEL DISPLAY
100-384118-19	01-0790080-00	POWER SUPPLY
100-9022-13	133-380070-13	LANDING GEAR CONTROL ASSY
10-381550-2	TGLN-28	IGNITION BOX
122-382015-11	501-1412-03	GYRO HORIZON
128-384045-5	55007-005	TURBINE RPM INDICATOR
128-384047-5	SEL-OC19BT	ITT INDICATOR
128-384054-1	11218-6	ICE PROTECTION CONTROLLER
201530-11373	130-380005-7	AIRSPEED INDICATOR
2-1580		MAIN BRAKE ASSEMBLY
23048-018	100-389005-11	STARTER GENERATOR
23078-019	23078-019	STARTER GENERATOR
23078-019A		DC STARTER GENERATOR
23080-050	45AS88801-017	STARTER GENERATOR
25700-22	112-380022-23	NOSE LANDING GEAR ACTUATOR
2587193-43	C14A	SLAVED DIRECTIONAL GYRO
2594484	FX-220	FLUX VALVE
2702-19		AIR PRESSURE REGULATOR
2801-01-3	133-380022-29	ELEC INSTRUMENTATION DISPLAY
30-215-8	473275	FIRE DETECTOR
3-1548-1		WHEEL ASSEMBLY
345MFD1-3	133-380022-37	ELEC INSTRUMENTATION DISPLAY
40-0100-XX		ANTI COLLISION LIGHT
400-8002-97	5010614	BRAKE ASSEMBLY
4020577-3	C14D	SLAVED DIRECTIONAL GYRO
45AS38202-017	5004190-6	BRAKE ASSEMBLY
45AS61015-13	100-TA1968-N4	FLAP FOLLOW UP
45AS63001-003	130356-9	PRESSURIZATION CONTROLLER
45AS63018-079	979580-5	MODULATING VALVE
45AS63018-XXX	VARIOUS	TEMP SENSOR

AVAILABLE FOR SALE, EXCHANGE OR MRO

HAWKER BEECHCRAFT



23078-019
DC STARTER GENERATOR



45AS8801-009 GCU



45AS8801-013
STARTER-GENERATOR



C-14 A
SLAVED GYRO SPERRY

AVAILABLE FOR SALE, EXCHANGE OR MRO

PART NUM.	ALT PART NUM.	DESCRIPTION
45AS68001-009	130358-3	PNEUMATIC RELAY
45AS86801-003	PC-820-116	SIGNAL CONDITIONER
45AS86825-009	397-04844	OIL PRESS/TEMP INDICATOR
45AS86848-001	522337	ROLL TRIM INDICATOR
45AS8856-005	76481-2	THRUST REVERSE CONTROL
45AS88801-009	FA13-2	GENERATOR CONTROL UNIT
45AS88801-013	FDG17-3A	STARTER GENERATOR
45AS88801-017	23080-050	STARTER GENERATOR
4712-21		FUEL SYSTEM SHUTOFF VALVE
5004190-6	45AS38202-017	BRAKE ASSEMBLY
501-1197-XX	AI-804-X	STANDBY HORIZON
501-1228-XX	PS835-X	EMERGENCY POWER SUPPLY
50284-03		DC PROTECTION PANEL
5412600-3		THRUST REVERSE CONTROL
586110-3		COOLING TURBINE
622-1270-001		TRANSPONDER
AA-34-12M1	45AS61014-107	TRIM ACTUATOR
APTE-2A-2250-85D	130-389002-3	ENG TORQUE PRESS TRANSMITTER
EM4132-2	133-380027-11	LINEAR ACTUATOR
EM6003-1	133-380068-1	BLOWER, VANE AXIAL
PC-450 SERIES		STATIC INVERTER
ST-502K-1	101-389005-3	TORQUE PRESSURE TRANSMITTER
VG-14A	700622-901	VERTICAL GYRO

PART NUM.	ALT PART NUM.	DESCRIPTION
0850420-X	1C6-10	BOOST PUMP
1821-1	1505-1	DIMMER
200SGL119Q		STARTER GENERATOR
205 SERIES	505-0031-XXX	DIRECTIONAL GYRO, ELECTRIC
23065-018-1		STARTER GENERATOR
23076-004-1		STARTER GENERATOR
23081-XXX		STARTER GENERATORS
300SGL-SERIES		STARTER GENERATORS
305-SERIES	504-0033-XXX	GYRO HORIZON, ELECTRIC
33E83-2	0901-1	VENT FAN
3E1443-5 OR -7	RA1543-5 OR -7	PROP DEICE BRUSH
3E2090-1	RA2190-1	PROP DEICE BRUSH MODULE
4000B SERIES	1U262-001-XX	DIRECTIONAL GYROS
40-0100-SERIES		BEACONS
4E2092-2	RA2192-2	PROP DEICE BOOT LEAD
5000F-SERIES	1U149-002-X	GYRO HORIZONS
51539-002M	51539-002M	GENERATOR CONTROL UNIT C441
51539-012N		GENERATOR CONTROL UNIT
570-24929-013	24929-013	ENCODING ALTIMETER
5934PAD-3A132		ALTIMETER
9910288-X	1C12-17	FUEL BOOST PUMP C441
9910292-2	23079-004	STARTER GENERATOR C441
9910338-X	DSFF1785-X	FUEL FLOW INDICATOR
9910368-2	60-2799-1	STROBE POWER SUPPLY
9910378-1	AG34	TACH GENERATOR
9910592-1 OR -2	C611505-SERIES	STANDBY ALTERNATOR
9912034-1	AG34	TACH GENERATOR
C145-350		FLAP MOTOR
C291504-SERIES	VARIOUS	FUEL BOOST PUMP
C661004-0101	1234T100-3ATZ	TURN & BANK
C661006-0101	30260-1117	IVSI
C661011-0201		SEN. PRESSURE ALTIMETER
C661014-XXXX		ALTIMETERS, 20K & 35K
C661025-XXXX	VARIOUS	ALTIMETER, MILLIBARS
C661063-XXXX	20240-11XXX	MACH AIRSPEEDS

AVAILABLE FOR SALE, EXCHANGE OR MRO

CESSNA



INVENTORY SUPPORTED MAINTENANCE, REPAIR AND OVERHAUL



Let us shed some light
on hard to find parts.


Authorized
Honeywell
AWARS

PAC
PRECISION AVIATION CONTROLS
A **PAG** Company

Call 620.331.8180 or visit us at
precisionaviationcontrols.com

Avionics
Hydraulics
Instruments
Wheels & Brakes
Starter Generators

Others sell parts, WE SELL SUPPORT™



Inventory Supported
Maintenance • Repair • Overhaul

PART NUM.	ALT PART NUM.	DESCRIPTION
C661064-SERIES	VARIOUS	AIRSPPEED INDICATORS
C661064-XXXX		AIRSPPEEDS
C661065-XXXX		TRUE AIRSPPEED
C661071-XXXX		ALTIMETERS, 20K & 35K
C661072-010X	VARIOUS	ALTIMETER
C661075-0101	200-5C	DIRECTIONAL GYRO
C661075-0103	RCA11A-9	DIRECTIONAL GYRO
C661076-XXXX	VARIOUS	GYRO HORIZONS, AIR
C662013-0101	DSF698-2	FUEL QUANTITY INDICATOR
C662019-0101	18C452-1	OIL TEMP & PRESS. INDICATOR
C662020-XXXX		DUAL FUEL FLOW INDICATORS
C662026-XXXX	6121-XX	DUAL MAN PRESS INDICATORS
C662037-XXXX	6033H-XX	MAN PRESS/FUEL FLOW
C662501-XXX	152LA30X	AMMETERS
C662502-0101		DC VOLTMETER
C664504-0101		24 HOUR CLOCK
C664510-0102	86000-1143	CLOCK
C664511-0102	LC-2	DIGITAL CLOCK
C668016-010X	512-0X	DUAL TACHOMETER
C668017-0101	511-01	DUAL TACHOMETER
C668017-010X	511-0X	3" TACHOMETER
C668017-XXXX	511-XX	DUAL TACHOMETER
C668020-0107		TACH INDICATOR
C668022-XXXX	5629-XX	DUAL TACHOMETERS
C668501-0211	45812	EGT INDICATOR
C668501-0213	46217	EGT INDICATOR
C668503-0201	46098	EGT INDICATOR
C668510-0401	162BL507D	OUTSIDE AIR TEMP INDICATOR
C668511-0102	3001-J14	CABIN ALT/DIFF PRESS INDICATOR
C668513-0101	35060-1128	CABIN RATE OF CLIMB
C668516-0104	3000-0104	CABIN ALT/DIFF PRESS INDICATOR
C668519-0101	09006-0126	SUCTION GAUGE
C668520-0101	310-167	TURN & BANK
C6SC1029-1	8DJ81CCL2	PERCENT TACH INDICATOR
C6SC1037-1	8DJ81CCM2	TACH INDICATOR

AVAILABLE FOR SALE, EXCHANGE OR MRO



AIM 505 SERIES
ELECTRIC HORIZONS



51539-012N
GCU



9910395-5
FUEL TOTALIZER



C661065-SERIES
AIRSPPEED INDICATOR



2-1528-6
BRAKE ASSEMBLY



066-1048-02
RADAR ALTIMETER



C668017-0106
3-INCH TACHOMETER



C661004-0101
TURN & SLIP

AVAILABLE FOR SALE, EXCHANGE OR MRO


PART NUM.	ALT PART NUM.	DESCRIPTION
C6SC1125	8190026	PRESSURE SWITCH
CM3302-1	C402-1	DUAL F/F INDICATOR
DSF859-1		FUEL QUANTITY INDICATOR
DSF989-X		FUEL GAUGE INDICATOR
G-1050A	47070-0008	FLIGHT DIRECTOR, AIR
G-300A	42320-0028	TURN COORDINATOR
G-500A	35060-0128	TURN COORDINATOR
G-519B-1	5000L-4	GYRO HORIZON
G-519FD SERIES	41100-00XX	FLIGHT DIRECTOR, AIR
G-520A	30370-0102	DIRECTIONAL GYRO, AIR
G-830A	41430-0000	TURN & SLIP, ELECTRIC
G-840A	43080-0000	TURN & SLIP, YAW DAMP
IG-832 SERIES	44690-XXXX	HORIZONTAL SITUATION INDICATOR
IG-895 SERIES	44680-XXXX	HORIZONTAL SITUATION INDICATOR
PC-15H		STATIC INVERTER
PC-17-3		STATIC INVERTER
PC-17-3B		STATIC INVERTER
PC-251		STATIC INVERTER C441
PC-50		STATIC INVERTER
RCA11 SERIES		DIRECTIONAL GYROS
RCA22 SERIES	102-0074-XX	GYRO HORIZON
S3100-249	060-00017-0000	GYRO HORIZON
S3291-1	1394T100	TURN COORD, KAP140
S3326-1	1U149-015-9	LIGHTED HORIZON
S3329-1	SL1010-001-1-1	TACH INDICATOR
S3330-1	1U262-010	DIRECTIONAL GYRO, AIR
S3330-2	1U262-042-2	DIRECTIONAL HORIZON
025493-402-05		ENGINE DRIVEN FUEL PUMP
030-18902	30-189B	BRAKE ASSEMBLY
066-1048-02	KRA-405	RADAR ALTIMETER
103576-26		SECONDARY OUTFLOW VALVE

PART NUM.	ALT PART NUM.	DESCRIPTION
10-381550-2		IGNITION EXCITER
109208-1	WF326022	FILTER ELEMENT
1169-1		HOT AIR TEMP MONITOR
1229-1		BATTERY TEMP MONITOR
13027-4		3-WAY VALVE
130358-1		PNEUMATIC RELAY
1505-1	1821-1	DIMMER
1529-1		BATTERY TEMPERATURE MONITOR
1630-1		AUDIO AMPLIFIER
1640-1		AUDIO PANEL
1821-1		DIMMER
1925757-2		HORIZONTAL SITUATION INDICATOR
1978121-1		VERTICAL GYRO
1U434-001	1U434-001	CONTROL PANEL
213100		ENGINE SYNC ACTUATOR
213723		ENGINE SYNC CONTROL

[CITATION]

PART NUM.	ALT PART NUM.	DESCRIPTION
2-1528-6	9912246-27	BRAKE ASSEMBLY
23080-001-1	9912038-4	STARTER GENERATOR
23080-003	9914052-9	STARTER GENERATOR
23080-003-1	9914052-12	STARTER GENERATOR
23085-004	9912125-4	STARTER GENERATOR
24929-013	570-24929-013	ENCODING ALTIMETER
25607-2		FLOW DIVIDER
2592920-044	RD-44	DEVIATION INDICATOR
2592920-901		HORIZONTAL SITUATION INDICATOR
2593379-1		REMOTE COMPENSATOR
2594484		VALVE FLUX
2710969		CONTROL VALVE
28711-503	525-28711-503	SERVOED ALTIMETER
300SGL129Q	9912125-2	STARTER GENERATOR
30-189A	030-18901	BRAKE ASSEMBLY

AVAILABLE FOR SALE, EXCHANGE OR MRO



PRECISION LANDING GEAR SUPPORT



*Multiple Ship-Sets Available
to ship Within 30 Minutes*

*Component Overhauls
& Exchanges*

Worldwide MRO Services

Main Landing Gear

Nose Landing Gear

Main Drag Brace

Drag Brace / Drag Leg

Shimmy Damper

Piston and Axle Assembly

Landing Gear Box W/O Motor

Main Landing Gear Shock Absorber



Inventory Supported
Maintenance • Repair • Overhaul

**NO AOG FEE
ALWAYS AVAILABLE**

**404.218.5777
WORLDWIDE**


Others
sell parts,
**WE SELL
SUPPORT**

INVENTORY LOCATIONS: ATL / KFFC / LFT / IDP / LAX / BNE / YVR / GRU / SIN

[CITATION]

PART NUM.	ALT PART NUM.	DESCRIPTION
30-189B	030-18902	BRAKE ASSEMBLY
30-2		POW BRAKE ASSEMBLY MOTOR
30660-1117	C661006-0201	IVSI
3-1490-1	9912222-11	MAIN WHEEL ASSEMBLY
3244759-3		FUEL CONTROL UNIT
3268014-0201		FUEL FLOW TRANSMITTER
38E85-5C		DE-ICE BOOT REGULATOR
391046-219	9912019-15	FUEL TRANSMITTER
391046-438	9912019-18	FUEL TRANSMITTER
4000504-0301		RADAR ANTENNA
4000763-3101		RADAR RECEIVER/TRANSMITTER
40-0100-1		NAV STROBE LIGHT
40-0100-21		BEACON LIGHT ASSEMBLY
4004437-901		RADIO ALTIMETER RECEIVER
4006719-904		ELEVATOR SERVO
4006719-906		AILERON SERVO
4008519-941		SP-200 AUTOPILOT COMPUTER
4013013-914		VERTICAL SPEED INDICATOR
4013241-931	AZ-241	AIR DATA COMPUTER
4018369-905		FLIGHT DIRECTOR COMPUTER
4018639-901		AUTOPILOT CONTROL
4020570-901		MODE SELECTOR
4020571-904		VNAV CONTROL
4020571-906		VNAV CONTROLLER
4020577-3		DIRECTIONAL GYRO
44929-013	9914549-1	ALTIMETER, ENCODING
5000472-1		SHUTTLE VALVE
5001445-1		BRAKE ASSEMBLY
5001445-4		BRAKE ASSEMBLY
5001446-4		BRAKE ASSEMBLY
5003783		MAIN WHEEL ASSEMBLY
501-1197-09	AI-804A/H	ATTITUDE GYRO
504-0035-906		HORIZON GYRO
511-0001-901		STANDBY GYRO POWER SUPPLY
51509-006BR	9912039-3	GENERATOR CONTROL UNIT
EM603-7	01-384135-3	BLOWER ASSEMBLY

AVAILABLE FOR SALE, EXCHANGE OR MRO

44929-013
ALTIMETER9912147-15
ITT INDICATOR991247-10
OIL PRESSURE
INDICATOR3244759-3
FUEL CONTROL UNIT



40-0100-1
NAV STROBE LIGHT



402571-904
NAV COMPUTER



30-2
PUMP MOTOR



7000622-901
VERTICAL GYRO

AVAILABLE FOR SALE, EXCHANGE OR MRO

PART NUM.	ALT PART NUM.	DESCRIPTION
522-2638-008	331A-3G	HORIZONTAL SITUATION INDICATOR
5543001-11		SHIMMY DAMPER
5543001-8		SHIMMY DAMPER
5703-3	9918002-1	BLOWER ASSEMBLY
5703-4	9918002-1	BLOWER
586110-SERIES		TURBINE COOLING ACM
60-1755-5		POWER SUPPLY
60-2799-1	9910368-2	STROBE POWER SUPPLY
622-0555-008	332C-10	RADIO MAGNETIC INDICATOR
622-1233-001		DME INTERROGATOR
622-2012-201		DME INDICATOR
622-2363-001		ADF RECEIVER
67410-1	9912086-7	SHUT OFF VALVE, HOT AIR PRESS
7000469-909	RD-650	HORIZONTAL SITUATION INDICATOR
7000622-901		VERTICAL GYRO
7000839-903		RADIO ALT INDICATOR
7003400-912		SYMBOL GENERATOR
7007453-903		RATE GYRO
912147-21	DG-OC203A	TURBINE SPEED INDICATOR
9544207		NOSE WHEEL ASSEMBLY
9912015-2	WF334597	FUEL FILTER
9912038-3	23076-001-1	STARTER GENERATOR
9912038-4	23080-001-1	STARTER GENERATOR
9912038-5	23080-025	STARTER GENERATOR
9912038-6	23085-004	STARTER GENERATOR
9912038-7	23076-001-1F	STARTER GENERATOR
9912125-3	23085-004-1	STARTER GENERATOR
9912125-4	23085-004	STARTER GENERATOR
9912147-10	VSDL-OC204C	OIL PRESSURE INDICATOR
9912147-10	VSDL-OC204H	OIL PRESSURE INDICATOR
9912147-11	VSDL-219C	OIL TEMP INDICATOR
9912147-11	VSDL-OC219F	OIL TEMP INDICATOR
9912147-12	VSDL-OC403A	FUEL FLOW INDICATOR
9912147-12	VSDL-OC403D-1	FUEL QUANTITY INDICATOR
9912147-15	VDSL-OC491E	ITT INDICATOR

PART NUM.	ALT PART NUM.	DESCRIPTION
9912147-15	VSDL-OC419H	ITT INDICATOR
9912147-18	VSDL-OC410N	FAN SPEED INDICATOR
9912147-18	VSDL-OC410T	FAN SPEED INDICATOR
9912147-19	VSDL-OC410S	FAN SPEED INDICATOR
9912147-20	VSDL-OC410R	FAN SPEED INDICATOR
9912147-22	VSDL-OC208F	FUEL FLOW INDICATOR
9912147-25	DDL-OC110A	TURBINE SPEED INDICATOR
9912147-26	VSDL-OC403F-1	FUEL QUANTITY INDICATOR
9912147-27	VSDL-OC410AE	FAN SPEED INDICATOR
9912147-28	DDL-OC110B	TURBINE SPEED INDICATOR
9912147-3	VSSL-OC204A	OIL PRESSURE INDICATOR
9912147-30	VSDL-OC204N	OIL PRESSURE INDICATOR
9912147-34	VSDL-OC419L	ITT INDICATOR
9912147-35	VSDL-OC410AF	FAN SPEED INDICATOR
9912147-36	DDL-OC110D	TURBINE SPEED INDICATOR
9912147-4	VDSL-OC419A	ITT INDICATOR
9912147-7	VSDL-OC203A	FUEL QUANTITY INDICATOR
991222-17	2-1529-7	BRAKE ASSEMBLY
9912222-4	30-161A	BRAKE ASSEMBLY
99124095-4	VSDL-OC419F	ITT INDICATOR
9912454-1	PC-350-4A	STATIC INVERTER
9912469-7	2-1588-1	BRAKE ASSEMBLY
9914050-1	51539-006D	GENERATOR CONTROL UNIT
9914052-1	23080-003	STARTER GENERATOR
9914052-8	23080-003-1	STARTER GENERATOR
9914095-10	DDL-OC119C	FUEL TEMP INDICATOR
9914095-2	VSDL-204D	OIL PRESSURE INDICATOR
9914095-5	VSDL-OC410K	FAN SPEED INDICATOR
9914136-9	2-1502-3	BRAKE ASSEMBLY
992246-27	2-1528-6	BRAKE ASSEMBLY
BC61A901-2		CABIN VENT BLOWER ASSEMBLY
C660501-0301		MAGNETIC COMPASS
C661004-0101		TURN & BANK INDICATOR
C661006-0101		VERTICAL SPEED INDICATOR
C661056-0202		HORIZON INDICATOR



2-1528-6
BRAKE ASSEMBLY



501-1228-04
POWER SUPPLY




9912147-15
ITT INDICATOR



C661056-0202
AIR HORIZON

AVAILABLE FOR SALE, EXCHANGE OR MRO


Wheels and brakes
without the friction.



Call 337.714.0850 or visit us at
heliparts.la

Avionics
Hydraulics
Accessories
Instruments
Starter Generators

Others sell parts, WE SELL SUPPORT®



Inventory Supported
Maintenance • Repair • Overhaul

[CITATION]

PART NUM.	ALT PART NUM.	DESCRIPTION
C661072-0101		STANDBY ALTIMETER
C662502-0101		VOLTMETER
C668510-0401		OAT INDICATOR
C668511-0102		CABIN PRESSURE INDICATOR
C668513-0101		CABIN ROC INDICATOR
C668515-0101		GYRO PRESSURE GAUGE
DG-OC110A		TURBINE RPM INDICATOR
PC-17	SPC-60	STATIC INVERTER
PC-17A	SPC-60E	STATIC INVERTER
PC-251-123E		STATIC INVERTER
PC-350		STATIC INVERTER
SPC-38B		STATIC INVERTER
SPC-60A		STATIC INVERTER
VSDL-OC19E		ITT INDICATOR
VSDL-OC204C		OIL PRESSURE INDICATOR
VSDL-OC208E		FUEL FLOW INDICATOR
VSDL-OC219C		OIL TEMP INDICATOR

[BOMBARDIER LEARJET]


PART NUM.	ALT PART NUM.	DESCRIPTION
130406-1		OUTFLOW VALVE
131348-3		TURBINE SPEED INDICATOR
131350-3		TURBINE SPEED INDICATOR
40-0100-1		ANTI-COLLISION LIGHT
5003096		BRAKE ASSEMBLY
5003096-4	6600330-7	BRAKE ASSEMBLY
5003096-6	5003096-6	BRAKE ASSEMBLY
5003096-7	6600330-21	BRAKE ASSEMBLY
5004913-3		MAIN WHEEL
501-1105-04	AI-804J	GYRO HORIZON
501-1228-04	PS835D	POWER SUPPLY
61-2008		POWER SUPPLY
65078-01	AP09V-8-01	HYDRAULIC PUMP



501-1105-04
GYRO HORIZON



131350-3
TURBINE TEMP INDICATOR



13406-1
OUTFLOW VALVE



5003096
BRAKE ASSEMBLY

AVAILABLE FOR SALE, EXCHANGE OR MRO



INVENTORY SUPPORTED MAINTENANCE, REPAIR AND OVERHAUL


[MITSUBISHI MU-2]



035A-986404-1
MU-2 CABIN ALTIMETER



035A-986411-1
MU-2 EGT INDICATOR



23046-007
MU-2 STARTER GENERATOR



3-1543-1
WHEEL

AVAILABLE FOR SALE, EXCHANGE OR MRO

PART NUM.	ALT PART NUM.	DESCRIPTION
030A-986403-001	PF25-N34 OR N37	FUEL QUANTITY INDICATOR
030A-986403-009	PF28-N41	FUEL QUANTITY INDICATOR
030A-986404-001	PF28-N4 OR N6	FUEL QUANTITY INDICATOR
035A-986411-001	502B10D	ITT INDICATOR
23046-007M		STARTER GENERATOR
23046-028		STARTER GENERATOR
23048-007		STARTER GENERATOR
3E1150-10	761-990	DE-ICE TIMER
51565-000R		GENERATOR CONTROL
935A-9510-001	AG34	TACH GENERATOR
935A-9515-001	G9950-1	BEACON
A700ZC-7	A700AAP	REVERSE CURRENT RELAY
IPTE-27-1000-4000SG	110019	HYDRAULIC OIL PRESSURE
IPTE-51F-1000-70D	PS 50153-2	ENGINE TORQUE PRESSURE
418-00044	130-020-3	OIL PRESSURE TRANSMITTER

[PILATUS PC-12]

PART NUM.	ALT PART NUM.	DESCRIPTION
030-16200	30-162	BRAKE ASSEMBLY
066-03125-2500		ED462 DISPLAY
066-04031-1121		GPS RECEIVER
071-01439-3100	CP-467	EFIS CONTROL PANEL
071-01519-0101		RADAR TRANSCEIVER
1134104-1		DC DRIVE MOTOR
23085-025		STARTER GENERATOR
23085-029		STARTER GENERATOR
30-244		BRAKE ASSEMBLY
3-1501		WHEEL ASSEMBLY
3-1543-1		WHEEL ASSEMBLY
40-203		WHEEL ASSEMBLY
40-289		WHEEL ASSEMBLY
40-424		WHEEL ASSEMBLY
501-1712-02		EMERGENCY POWER SUPPLY

[PIPER CHEYENNE]

PART NUM.	ALT PART NUM.	DESCRIPTION
25700-SERIES	57-5AW	DUAL TACH INDICATORS
29146-02	3571251-9209	TORQUE INDICATOR
29287-02	3567411-6003	TORQUE TRANSMITTER
29470-02	3571262-2308	TACH INDICATOR
489-401	9133-25-B1	FUEL FLOW TRANSMITTER
49389-02	3265013-0601	FUEL FLOW INDICATOR
49677-02	3571262-2306	TACH INDICATOR
51198-00	3571214-6004	TORQUE INDICATOR
548-452	1394T100-7Z	TURN COORDINATOR

[ATR 42 & 72]

PART NUM.	ALT PART NUM.	DESCRIPTION
0-17-941.22.05.0.AA.B	6878400100	QUARTZ CLOCK
4013013-906	VS-200	VERTICAL SPEED IND
559-012B		INVERTER
64141-362-1		STANDBY ALTIMETER
64141-372-1		STANDBY ALTIMETER
7002638-907	DS-125A	TAS/TEMPERATURE INDICATOR
7002860-909	SI-285	MACH AIRSPEED INDICATOR
748-522-2		FUEL QUANTITY INDICATOR
748-722		FUEL QUANTITY REPEATER
748-724		FUEL QUANTITY INDICATOR
749-188		TRIPLE PRESS INDICATOR
796-966		FUEL QTY PRESELECTOR
8260-120		STARTER GENERATOR
8260-121		STARTER GENERATOR
940-605-SERIES	68-303-009-00	FUEL FLOW INDICATORS

AVAILABLE FOR SALE, EXCHANGE OR MRO



7000622-901
VERTICAL GYRO



9133-25-B1
FUEL FLOW TRANSMITTER




548-452
TURN COORDINATOR



700-2860-909
MACH AIRSPEED
INDICATOR



1C64-5
FUEL PUMP ASSEMBLY



1H98-2
FLOW CONTROL VALVE



F7-51-5
ELECTRONIC CONTROLLER



The Fluid Systems Division of Parker Aerospace is the premier global leader providing fluid management and electronic control systems for aerospace markets through innovative solutions.

Precision STOCKS over \$4MM in New and Overhauled Parker Aerospace Fuel, Lubrication and Pneumatic products. Call us today to learn more about our Parker Product Line Support.

PART NUM.	ALT PART NUM.	DESCRIPTION
F7-51-5	101-380025-17	ELECTRONIC CONTROLLER
F7-51-3	101-380025-11	ELECTRONIC CONTROLLER
363350-1003	9070B011-02	FLAP VELOCITY SENSOR
321100-1003		RUDDER POWER CONTROL UNIT
1H75-5	101-380027-1	BLEED AIR VALVE
1H75-14		REGULATOR VALVE
1H75-12	101-380027-3	REGULATOR & RELIEF VALVE ASSEMBLY
1H75-10		AIR REGULATOR
3B7-4		FUEL PUMP
2C6-8		FUEL PUMP
2C27-4		FUEL PUMP CARTRIDGE
2B7-34		FUEL PUMP
2B7-1		FUEL BOOST PUMP
1H98-2	101-380025-21	FLOW CONTROL VALVE
1D2-17	C6SC1005-5	FUEL BOOST PUMP
1D2-16	50-380177-9	FUEL BOOST PUMP
1D2-12	50-380177-5	FUEL BOOST PUMP
1C7-12	9912017-3	FUEL PUMP
1C64-5	118-389006-5	FUEL BOOST PUMP
1C27-18	118-389006-5	FUEL PUMP CARTRIDGE
1C15-7		FUEL BOOST PUMP
1C12-3		FUEL BOOST PUMP
1C12-1	50-389094-5	FUEL BOOST PUMP

[JETSTREAM 31/32]

PART NUM.	DESCRIPTION
10147	OVERSPEED WARNING SWITCH
153LCA8	DC AMMETER
2-1522-1	BRAKE ASSEMBLY
224-929-001	FUEL FLOW INDICATOR
224-929-002	FUEL FLOW INDICATOR
23079-SERIES	STARTER GENERATORS
2587193-43	GYROSYN COMPASS
267-937-005	FUEL FLOW INDICATOR
29-4000	CABIN TEMPERATURE INDICATOR
3000-J37	CABIN DIFFERENTIAL PRESSURE INDICATOR
32005-SERIES	TACH GENERATORS
39948-B2236	MAX AIRSPEED
3E1872-5	DE-ICE AMMETER
4020531-574	FLIGHT DIRECTOR INDICATOR
444-00522-400	OXYGEN CYLINDER PRESSURE INDICATOR
4A58.22.40F.00.0.D	CABIN RATE OF CLIMB INDICATOR
502/2	BATTERY TEMPERATURE MONITOR
51509-SERIES	GENERATOR CONTROL UNITS
51539-SERIES	GENERATOR CONTROL UNITS
60-2667-1	POWER SUPPLY
60-3146-3	POWER SUPPLY
61001-16	EGT INDICATOR
61001-44A	EGT INDICATOR
6931-700	PRESSURE GAUGE
696-2-12	TRIPLE INDICATOR
7000622-901	VERTICAL GYRO
8DJ81WCX4	TACH INDICATOR

AVAILABLE FOR SALE, EXCHANGE OR MRO



10147
OVERSPEED
WARNING SWITCH



23079-000
STARTER-GENERATOR



8DJ81WCX4
TACHOMETER INDICATOR



51509 GCU


[BOMBARDIER DH-8]



1827-SERIES
5VOLT DIMMER



2-1599
DASH 8 BRAKE ASSEMBLY



60-2799-3
STROBE POWER SUPPLY



8SC0271
FUEL TEMP INDICATOR


AVAILABLE FOR SALE, EXCHANGE OR MRO

PART NUM.	ALT PART NUM.	DESCRIPTION
10013-0000-02	8SC0050	FUEL QUANTITY MASTER INDICATOR
10014-0000-02	8SC0051	FUEL QUANTITY REPEATER IND
10014-0000-02	8SC0051	FUEL QUANTITY INDICATOR
10167N01W00	8SC0053	TORQUE PRESSURE INDICATOR
10167N02W00	8SC0359	TORQUE PRESSURE INDICATOR
10168N01T00	8SC0055	TURBINE TEMPERATURE INDICATOR
10169N01R00	8SC0054	PROPELLER TACH INDICATOR
10169N02R00	8SC0054	PROPELLER RPM INDICATOR
10170N01R00	8SC0056	HIGH PRESS ROTOR SPEED (NH) IND
10171N01F01	8SC0057	FUEL FLOW INDICATOR
10175N01T00	8SC0325	TURBINE TEMPERATURE INDICATOR
10177N01R00	8SC0323	HIGH PRESS ROTOR SPEED (NH) IND
13TX-0115-A	7SC0284	CONTROL SURFACE POS TRANSMTR
1827-1		5 VOLT DIMMER
21140-1134-2	8SC0109	AIRSPED INDICATOR
21140-1134-2	8SC0109	AIRSPED INDICATOR
21140-1150	8SC0345	AIRSPED INDICATOR
2-1466-3		MAIN BRAKE ASSEMBLY
2-1466-4		MAIN BRAKE ASSEMBLY
2-1466-5		BRAKE ASSEMBLY
2-1517, 2-1517-1		MAIN BRAKE ASSEMBLY
2-1565		MAIN BRAKE ASSEMBLY
2-1599		BRAKE ASSEMBLY
23088-SERIES		STARTER GENERATORS
2587193-43	C-14A	DIRECTIONAL GYRO
28VS200Y-4DH		TRANSFORMER RECTIFIER UNITS
3001-SERIES		FIRE DETECTORS
300SGL127Q		STARTER GENERATORS
30-231-SERIES		SMOKE DETECTORS
30-326E-7		FIRE DETECTION AMP
31400-007		STANDBY ALTIMETER
3-1442		NOSE WHEEL ASSEMBLY
3601-SERIES		OVERHEAT DETECTOR
3D1472-11	7SC0113	DE-ICE TIMER
4012373-906	SM-710	SERVO ACTUATOR

PART NUM.	ALT PART NUM.	DESCRIPTION
016341-905	BA-141	ALTIMETER
40-603-2	8SC0067	SPOILER POSITION INDICATOR
4349-150-80-10	8SC0152	RUDDER TRIM POSITION INDICATOR
51539-SERIES		GENERATOR CONTROL UNITS
522456	8SC0085	HYDRAULIC PRESSURE INDICATOR
522457	8SC0118	DUAL DE-ICE PRESSURE INDICATOR
522458	8SC0070	HYDRAULIC PRESSURE INDICATOR
522459	8SC0079	CABIN DUCT TEMPERATURE IND
522484	8SC0152	RUDDER TRIM INDICATOR
522485	8SC0065	FLAP POSITION INDICATOR
522487-1	8SC0132	BATTERY TEMPERATURE MONITOR
522778	8SC0073	DC POWER INDICATOR
522790	8SC0249	FUEL TEMPERATURE INDICATOR
522808	8SC0072	AC POWER INDICATOR
522848	8SC0202	ENGINE OIL PRESS/OIL TEMP IND
522849	8SC0160	DUAL LOW PRESSURE INDICATOR
522942	8SC0065	FLAP POSITION INDICATOR
522945	8SC0271	FUEL TEMPERATURE INDICATOR
523115	8SC0152	RUDDER TRIM INDICATOR
523188	8SC0065	FLAP POSITION INDICATOR
523244	8SC0249	FUEL TEMPERATURE INDICATOR
523281	8SC0326	ENGINE OIL PRESS AND TEMP IND
5346-220-80-10	8SC0079	CABIN DUCT TEMPERATURE IND
5347-700-80-10	8SC0160	DUAL LP ROTOR SPEED (NL) IND
5348-200-80-10	8SC0271	FUEL TANK TEMPERATURE IND
535201-1	8SC0161	LANDING GEAR SELECTOR
5427-115-80-10	8SC0070	DUAL HYDRAULIC PRESSURE IND
5427-116-80-10	8SC0118	DUAL DE-ICE PRESSURE INDICATOR
5427-218-80-10	8SC0249	DUAL FUEL TEMPERATURE IND
5427-361-80-10	8SC0326	DUAL ENG OIL PRESS/OIL TEMP IND
5428-150-80-10	8SC0085	PARK BRAKE HYDR PRESS IND
5550-8340-N1L	7SC0082	TURN & BANK INDICATOR
60-2799-3		STROBE POWER SUPPLY
6700-300-80-10	8SC0072	AC POWER INDICATOR
6700-400-80-10	8SC0073	DC POWER INDICATOR

AVAILABLE FOR SALE, EXCHANGE OR MRO





Your Premier Service Center
in the Southeast.

PAS
PRECISION AIRCRAFT SERVICES
A **PAG** Company

Call 770.486.6061 or visit us at
pas-pag.com

Paint
Interiors
Inspections
Maintenance
ADS-B Upgrades

Others sell parts, WE SELL SUPPORT®



Inventory Supported
Maintenance • Repair • Overhaul

[BOMBARDIER DH-8]

PART NUM.	ALT PART NUM.	DESCRIPTION
6700-400-80-11	8SC0073	DC POWER INDICATOR
6800-100-80-10	8SC0132	BATTERY TEMPERATURE MONITOR
7000622-901	VG-14A	VERTICAL GYRO
70-0253-7	8SC0026	ADVISORY LIGHT CONTROL
754890-(X)		CABIN TEMP CONTROLLER
7SC0077	SLZ9464-A1	VERTICAL SPEED INDICATOR
7SC0077	SLZ9464A-1	CLIMB INDICATOR
7SC0082	VARIOUS	TURN & BANK INDICATOR
7SC0361	811B-24	CLOCK
80-0535-(X)		ANNUNCIATOR LIGHT PANEL
8047/10DH	7SC0365	ALTIMETER
811B24	7SC0361	CLOCK
8SC0050	10013-0000-02	FUEL QUANTITY MASTER INDICATOR
8SC0051	10014-0000-02	FUEL QUANTITY REPEATER IND
8SC0053	SEDL-OC2P	TORQUE PRESSURE INDICATOR
8SC0054	10169N02R00	PROPELLER TACH INDICATOR
8SC0054	SEL-OC29DF	PROPELLER TACH INDICATOR
8SC0055	SEL-OC19DW	TURBINE TEMPERATURE INDICATOR
8SC0056	SEL-OC29DA	HIGH PRESS ROTOR SPEED (NH) IND
8SC0057	SEL-OC8J	FUEL FLOW INDICATOR
8SC0057	SEL-OC8G	FUEL FLOW INDICATOR
8SC0065	4428-150-80-10	FLAP POSITION INDICATOR
8SC0068	SRDL-OC12F	DUAL HYDRAULIC QUANTITY IND
8SC0070	522458	HYDRAULIC PRESSURE INDICATOR
8SC0072	6700-300-80-10	AC POWER INDICATOR
8SC0073	6700-400-80-11	DC POWER INDICATOR
8SC0079	5346-220-80-10	CABIN DUCT TEMPERATURE IND
8SC0085	522456	HYDRAULIC PRESSURE INDICATOR
8SC0098	SETL-OC420F	CABIN PRESSURE INDICATOR
8SC0109	21140-1134-2	AIRSPEED INDICATOR
8SC0118	522457	DUAL DE-ICE PRESSURE INDICATOR
8SC0132	522487-1	BATTERY TEMPERATURE MONITOR
8SC0152	522484	RUDDER TRIM INDICATOR
8SC0158	4350-150-80-10	AILERON TRIM INDICATOR
8SC0160	522849	DUAL LOW PRESSURE INDICATOR



8047-10DH
ALTIMETER



SLZ-9464A-1
IVSI



C-14A
SLAVED DG SPERRY



8SC0271 FUEL
TEMP INDICATOR

AVAILABLE FOR SALE, EXCHANGE OR MRO

[BOMBARDIER DH-8]



6700-300-8-10
AC POWER MONITOR.



522849
LOW PRESSURE ROTOR SPEED
INDICATOR



8SC0053
TORQUE INDICATOR



8SC0054
RPM PROP INDICATOR

AVAILABLE FOR SALE, EXCHANGE OR MRO

PART NUM.	ALT PART NUM.	DESCRIPTION
8SC0202	522848	ENGINE OIL PRESS & TEMP IND
8SC0249	5427-218-80-10	DUAL FUEL TEMPERATURE IND
8SC0271	522945	FUEL TEMPERATURE INDICATOR
8SC0323	10177N01R00	HIGH PRESS ROTOR SPEED (NH) IND
8SC0325	10175N01T00	TURBINE TEMPERATURE INDICATOR
8SC0326	5427-361-80-10	DUAL ENG OIL PRESS/OIL TEMP IND
8SC0345	21140-1150	AIRSPEED INDICATOR
8SC0359	SEDL-OC2S	ENGINE TORQUE INDICATOR
C-14A	2587193-43	SLAVED DIRECTIONAL GYRO
H321ALM1		STANDBY GYRO HORIZON
SEL-OC19DW	8SC0055	TURBINE TEMPERATURE INDICATOR
SEL-OC29DA	8SC0056	HIGH PRESS ROTOR SPEED (NH) IND
SEL-OC2N	8SC0053	TORQUE PRESSURE INDICATOR
SEL-OC8J	8SC0057	FUEL FLOW INDICATOR
SETL-OC420F	8SC0098	CABIN PRESSURE INDICATOR
SRDL-OC12F	8SC0068	HYDRAULIC QUANTITY INDICATOR
SYLZ50970	8SC0165	WINDSHIELD TEMP CONTROLLER
VG-14A	7000622-901	VERTICAL GYRO

[BOMBARDIER CRJ]

PART NUM.	ALT PART NUM.	DESCRIPTION
19A2991		CABIN VANE AXIAL FAN
5361-1-5	601R50999-5	AUDIO CONTROL PANEL
5361-1-7	5340	AUDIO CONTROL PANEL
SPC-10(V)	601R59323-1	STATIC INVERTER
WL102AMS5		ALTIMETER/AIRSPEED INDICATOR



INVENTORY SUPPORTED MAINTENANCE, REPAIR AND OVERHAUL

[BEECHCRAFT 99]

PART NUM.	ALT PART NUM.	DESCRIPTION
100-0034-SERIES	VARIOUS	TACHOMETERS
100-380011-1	2-1573	BRAKE ASSEMBLY
100-384040	27-6	FLAP MOTOR ASSEMBLY
100-384048-SERIES	SR-2 SERIES	TORQUE INDICATORS
100-384050-SERIES	SR-94 SERIES	OIL PRESS INDICATORS
100-384054-SERIES	VARIOUS	IVSI
100-384117-SERIES	VARIOUS	OIL TEMP/OIL PRESS
100-389004	ST-502G	OIL PRESS TRANSMITTER
100-389007	ST-504AB-1	OIL PRESS TRANSMITTER
100-524073-1		FLAP MOTOR & GEARBOX
101-360020-SERIES	40-0127-SERIES	OSC BEACON
101-364270-5	51530-007B	GENERATOR CONTROL UNIT
101-380030-SERIES	VARIOUS	TURN & SLIP, AIR
101-380031-SERIES	VARIOUS	TURN & SLIP, ELECTRIC
101-381012-SERIES	4711-SERIES	BLEED AIR SHUTOFF VALVES
101-384092-1	VARIOUS	CLOCK
101-384120-1	500E	GYRO HORIZON
101-384135-3	EM603-7	BLOWER ASSEMBLY
101-384150-7	300-903-006	FUEL QUANTITY INDICATOR
101-384151-SERIES	81-101-SERIES	FUEL QUANTITY INDICATORS
101-388005-SERIES	20600-SERIES	HYDRAULICS POWER PACKS
101-389007-1	23048-016	STARTER GENERATOR
101-389025-1	AV16B1700B	FIREWALL SHUTOFF VALVE
115-380002-5	40-6	LANDING GEAR MOTOR
115-384011-SERIES	3571111-SERIES	OIL PRESS INDICATORS
115-384012-SERIES	5014-10 SERIES	OIL TEMP INDICATORS
115-384014-SERIES	VARIOUS	TORQUE INDICATORS
115-384023	3571810-0003	FUEL FLOW INDICATOR
213100	5485-006	PROP SYNCH ACTUATOR
213350	757-912	PROP SYNCH CONTROL BOX
30301102		FIRE BOTTLE ASSEMBLY
332-E4	522-3241-000	SLAVED DIRECTIONAL GYRO
3E1964-3	2-1138	DE-ICE TIMER
4000B-SERIES	VARIOUS	DIRECTIONAL GYROS, AIR
4E1188-3	RA1288-3	PROP DE-ICE BOOT

AVAILABLE FOR SALE, EXCHANGE OR MRO



3E1964
DE-ICE TIMER



50-380034-3
TURBINE TACH INDICATOR



50-384203-3 GYRO HORIZON



100-389007
OIL PRESSURE
TRANSMITTER

PRECISION WHEELS & BRAKES



Over 10,000 wheels & brakes serviced in the past 3 years

Most models serviced from all major manufacturers

Quick turnaround on overhauls

AVAILABILITY

Over 400 LRU's available to ship within 30 minutes

QUALITY

Airline and Fleet Operators demand our kind of diligence

FLEXIBILITY

Sales, repairs, exchanges & overhauls as you need them



Inventory Supported
Maintenance • Repair • Overhaul

**NO AOG FEE
ALWAYS AVAILABLE**

**404.218.5777
WORLDWIDE**

Others
sell parts,
**WE SELL
SUPPORT**


EXCHANGES ARE AVAILABLE 24/7

[BEECHCRAFT 99]

PART NUM.	ALT PART NUM.	DESCRIPTION
4E1188-5	RA1288-5	PROP DE-ICE BOOT
4E1889-2	RA1989-2	DE-ICE BOOT LEAD
500DCF	504-0010-909	GYRO HORIZON
500ECFB	504-0002-918	GYRO HORIZON
50-380024	VARIOUS	TURN & BANK
50-380034-SERIES	VARIOUS	TURBINE TACH INDICATORS
50-380035-SERIES	VARIOUS	PROP TACH INDICATORS
50-380094-5	1C12-1	FUEL BOOST PUMP
50-380107-SERIES	217-SERIES	TORQUE PRESS TRANSMITTERS
50-380108	418-08014	TORQUE PRESS TRANSMITTERS
50-380177-5	1D2-12	FUEL BOOST PUMP
50-384073	7040B	CLIMB INDICATOR
50-384203	23-501-016-1	ATTITUDE GYRO, AIR
50-384205	1U262-001-11	DIRECTIONAL GYRO, AIR
50-389044-11	A210507	OVERSPEED GOVERNOR
50-389057-1	VARIOUS	TACH GENERATORS
50-389091	22-280-026-1	PROP SYNCH INDICATOR
50-389095	AV1B1602	CROSS FEED VALVE
50-389102-SERIES	5006-10 SERIES	TURBINE TEMP INDICATOR
50-521222-SERIES	VARIOUS	FLAP ACTUATORS
50-521223-SERIES	VARIOUS	FLAP ACTUATORS
51530-SERIES		GENERATOR CONTROLS
51538-SERIES		GENERATOR CONTROLS
58-380069-5	VARIOUS	STANDARD ALTIMETER
58-380085-SERIES	VARIOUS	TURN COORDINATORS
58-380094-SERIES	VARIOUS	TURN COORDINATORS
6852-920	213499	PROP SYNCHROPHASER
8210-SERIES	VARIOUS	PROP GOVERNORS
8DJ81-SERIES		TACH INDICATORS
90-380029-3	90033-17	BEACON ASSEMBLY
90-384026-SERIES	VARIOUS	ITT INDICATOR
9133-25-B1		FUEL FLOW TRANSMITTER
91-380018-1	VARIOUS	TURN & SLIP, AIR
91-380019-1	VARIOUS	TURN & BANK, 2 INCH ELEC
97-384009-SERIES	SRSW-94 SERIES	OIL PRESSURE INDICATORS

AVAILABLE FOR SALE, EXCHANGE OR MRO

BEECHCRAFT



[BEECHCRAFT 99]



418-00051
OIL PRESSURE
TRANSDUCER



1013642705
GCU



1234T100-SERIES
TURN & BANK INDICATOR



90-384026-23
ITT INDICATOR

AVAILABLE FOR SALE, EXCHANGE OR MRO

PART NUM.	ALT PART NUM.	DESCRIPTION
97-389002	ST-502F	TORQUE PRESSURE TRANSMITTER
99-384030-SERIES	SR-2A SERIES	TORQUE INDICATORS
99-384044-SERIES	VARIOUS	PITCH TRIM INDICATORS
99-388004-SERIES	VARIOUS	STEERING ACTUATORS
99-389014	ST-502H	TORQUE PRESSURE TRANSMITTER
A210632	101-389000-3	OVERSPEED GOVERNOR
A213796		SYNCHROPHASER CONTROL
AN5786-1	VARIOUS	FLAP POSITION TRANSMITTER
EM8001	TG255-002	TACH GENERATOR
VR1010-24-1A		VOLTAGE REGULATOR

[BEECHCRAFT 1900]

PART NUM.	ALT PART NUM.	DESCRIPTION
066-3062-00	KEA346	ENCODING ALTIMETER
101-380031-3	9550B N577	TURN & BANK
101-384137-SERIES		LANDING GEAR CONTROL
101-384233-1	MD69-1	VOLT/AMMETER
114-320052-3		FIRE PULL HANDLE
114-364140-7		CIRCUIT BOARD
114-380002-5	10657D	HEAT EXCHANGER
114-380005-5	SRL-C2K	TORQUE PRESSURE INDICATOR
114-380011-3	056-0020-01	TURN & BANK
114-380013-1	1U367-301-1	ATTITUDE GYRO, AIR
114-380014-1	4000B-27	DIRECTIONAL GYRO, AIR
114-380015-1	690027-1	PROP SYNCH INDICATOR
114-380018-1	35060-1175	CABIN CLIMB INDICATOR
114-380040-1	22E69-1	TEMP CONTROL VALVE
114-380041-7	7-5041-7	MAIN GEAR ACTUATOR
114-380045-3		POWER STEERING ACTUATOR
114-380046-5		BLEED AIR VALVE
114-380048-1	MD113-1	OXYGEN OUTLET INDICATOR
114-380049-5	563-267	DUAL PROP-AMMETERS
114-380049-7	563-305	DUAL PROP-AMMETERS

INVENTORY LOCATIONS: ATL / KFFC / LFT / IDP / LAX / BNE / YVR / GRU / SIN

PART NUM.	ALT PART NUM.	DESCRIPTION
114-380049-9	MD95-5	DUAL PROP-AMMETERS
114-380051-1	3701-10	LIFT TRANSDUCER
114-380057-1	RCA22-30	GYRO HORIZON, AIR
114-380057-5	RCA22-33	GYRO HORIZON, AIR
114-380058-1	504-0038-902	GYRO HORIZON, ELECTRIC
114-380058-3	504-0038-904	GYRO HORIZON, ELECTRIC
114-380059-5	1925-00-3	PRESSURE REGULATOR
114-380063-5	55003-004	TURBINE TACH INDICATOR
114-380064-5	55002-004	PROPELLER TACH INDICATOR
114-381002-SERIES	4711-SERIES	BLEED AIR SHUTOFF VALVES
114-381023-7	SX7EL11-4	DC POWER PANEL
332E-02	522-3241-000	SLAVED DIRECTIONAL GYRO

[CASA 212]

PART NUM.	ALT PART NUM.	DESCRIPTION
1234T100-7TZ		TURN & BANK INDICATOR
124.560-1		TORQUE INDICATOR
162B243		OIL TEMP INDICATOR
217-04111		FUEL PRESSURE INDICATOR
217-05111		DE-ICE PRESSURE INDICATOR
217-08151		OIL PRESSURE INDICATOR
23079-005		STARTER GENERATOR
2C27-2		FUEL BOOST PUMP
30-1033-19		STROBE LIGHT
30-231-3		SMOKE DETECTOR
3E1443-1	RA-1534-1	PROP DE-ICE BRUSH
3E2042-1		PROP DE-ICE BRUSH ASSEMBLY
4002963-445		RH-445 RMI
4020501-300		GH-14A FLIGHT DIRECTOR IND
418-00051		OIL PRESSURE TRANSMITTER
418-02064		OIL PRESSURE TRANSMITTER
4E1889-2		DE-ICE BOOT LEAD
4E2092-2		PROP DE-ICE BOOT



50-380035-5
PROP TACH INDICATORS



30-321-3
SMOKE DETECTOR




418-00051
OIL PRESS TRANSMITTER



124
TORQUE INDICATOR

AVAILABLE FOR SALE, EXCHANGE OR MRO

Your source for instruments
requires little navigation.




PHP 
PRECISION HELIPARTS CANADA
A **PAG** Company

Call 604.542.8820 or visit us at
heliparts.ca

Avionics
Hydraulics
Accessories
Wheels & Brakes
Starter Generators

Others sell parts, WE SELL SUPPORT™




Inventory Supported
Maintenance • Repair • Overhaul

[DEHAVILLAND DH-6]

PART NUM.	ALT PART NUM.	DESCRIPTION
101627-01696		ENCODING ALTIMETER
1426-1Z-A1		AIRSPEED INDICATOR
1532-SERIES		DE-ICE DISTRIBUTION VALVES
200D(X) SERIES	505-0002-SERIES	DIRECTIONAL GYRO, DC ELEC
23048-SERIES		STARTER GENERATORS
241CC		VACUUM PUMP
250SG115Q		STARTER GENERATOR
3010820	A5278110302	TACH GENERATOR
318-100		OIL PRESSURE TRANSMITTER
318-SERIES		PRESSURE TRANSDUCERS
32005-SERIES		TACH GENERATORS
328A-3G	522-2644-011	SLAVING ACCESSORY
331A-3F	522-3082-SERIES	COURSE INDICATORS
331A-3G	522-2638-SERIES	COURSE INDICATORS
332-E4	522-3241-000	SLAVED DIRECTIONAL GYRO
3E1150-10		DE-ICE TIMER
3E2090-1	RA2190-1	PROP DE-ICE BRUSH ASSY
418-00044		OIL PRESSURE TRANSMITTERS
418-01064		TORQUE PRESSURE TRANSMITTERS
4E1889-2	RA1989-2	PROP DE-ICE BOOT LEAD
5000B-SERIES	23-501-06-SERIES	GYRO HORIZONS, AIR
510-SERIES	504-0017-SERIES	GYRO HORIZONS, ELECTRIC
559-1		FLAP POSITION TRANSMITTER
60-1755 SERIES		STROBE SUPPLIES
7030 SERIES		VERTICAL SPEED INDICATORS
8TJ9PFF44		FLAP POSITION TRANSMITTER
9133-25-B1		FUEL FLOW TRANSMITTER
9550377-4		BRAKE ASSEMBLY
A5278110302		TACH GENERATOR
A700AAP		REV CURRENT RELAY
A701D		REV CURRENT RELAY
AN5786-1	VARIOUS	FLAP POSITION TRANSMITTER
C6SC1005-1	RR12830A	FUEL BOOST PUMP
C6SC1005-5	2B7-1	FUEL BOOST PUMP
C6SC1026-1	217-03221	TORQUE PRESSURE INDICATOR

AVAILABLE FOR SALE, EXCHANGE OR MRO

DEHAVILLAND





GEU/7A
TACH GENERATOR



C6SC1090-1
TORQUE PRESS INDICATOR



7SC0082
TURN AND BANK
INDICATOR



32005-SERIES
TACH GENERATOR

AVAILABLE FOR SALE, EXCHANGE OR MRO

PART NUM.	ALT PART NUM.	DESCRIPTION
AN5786-1	VARIOUS	FLAP POSITION TRANSMITTER
C6SC1005-1	RR12830A	FUEL BOOST PUMP
C6SC1005-5	2B7-1	FUEL BOOST PUMP
C6SC1026-1	217-03221	TORQUE PRESSURE INDICATOR
C6SC1026-3	217-04221	TORQUE PRESSURE INDICATOR
C6SC1027-1	290-02240	OIL PRESSURE INDICATOR
C6SC1027-5	290-03240	OIL PRESSURE INDICATOR
C6SC1028-7	152B206	TURBINE TEMPERATURE INDICATOR
C6SC1029-1	8DJ81CCL2	TURBINE TACH INDICATOR
C6SC1029-3	34107C1AG13-1A3	TURBINE TACH INDICATOR
C6SC1029-3	3571260-7001	TURBINE TACH INDICATOR
C6SC1030-7	163B103A	OIL TEMPERATURE INDICATOR
C6SC1030-9	163B103B	OIL TEMPERATURE INDICATOR
C6SC1037-7	3571260-8003	PROPELLER TACH INDICATOR
C6SC1084-3	77749-122A5-1	OIL PRESSURE TRANSMITTER
C6SC1084-3	3567749-9502	OIL PRESSURE TRANSMITTER
C6SC1084-5	3567749-7103	TORQUE PRESSURE TRANSMITTER
C6SC1085-5	PW727MV/BU/44/700	TURBINE TEMPERATURE INDICATOR
C6SC1089-1	25510-A122A-8-A2	OIL PRESSURE INDICATOR
C6SC1089-1	3571810-0007	OIL PRESSURE INDICATOR
C6SC1090-1	25122-A121C-2-83	TORQUE PRESSURE INDICATOR
C6SC1090-1	3571212-0003	TORQUE PRESSURE INDICATOR
C6SC1115	217-09261	TORQUE PRESSURE INDICATOR
C6SC1115	217-09262	TORQUE PRESSURE INDICATOR
C6SC1116	418-01064	TORQUE PRESSURE INDICATOR
GEU/7A		TACH GENERATORS
KCA0104W		WET COMPASS
M5000-08		TURN & SLIP
M5861AD-6B		VANAXIAL FAN
PC INVERTER SERIES		STATIC INVERTERS
RCA15BK-SERIES	VARIOUS	ELECTRIC DIRECTIONAL GYROS
RCA26BK-SERIES	VARIOUS	ELECTRIC HORIZONS
RCA30 SERIES	VARIOUS	TURN & SLIP
VR1010-24 SERIES		VOLTAGE REGULATORS
7SC0232	DSN1967-1, -3, -5	ENG GAS GENERATOR TACH

[DEHAVILLAND DH-7]

PART NUM.	ALT PART NUM.	DESCRIPTION
2-1329-3	7SC0018	BRAKE ASSEMBLY
23088-SERIES		STARTER GENERATORS
30-231-3		SMOKE DETECTOR
30-326-1		FIRE AMP CONTROL
32005-SERIES		TACH GENERATOR
383093-019	7SC0056	FUEL QUANTITY INDICATOR
393008-053	7SC0055	FUEL QUANTITY INDICATOR
3D1472-11	7SC0113	DE-ICE TIMER
418-02084	7SC0069	OIL PRESSURE TRANSMITTER
418-09064	7SC0098	TORQUE PRESSURE TRANSMITTER
51539-SERIES		GENERATOR CONTROL UNITS
520-2BG	504-0035-906	GYRO HORIZON
60-1321-1		LIGHT POWER SUPPLY
60-2799-3		STROBE POWER SUPPLY
7SC0055	393008-053	FUEL QUANTITY INDICATOR
7SC0056	383093-019	FUEL QUANTITY INDICATOR
7SC0069	418-02084	OIL PRESSURE TRANSMITTER
7SC0075	245030	DC VOLTMETER
7SC0076	245040	DC LOADMETER
7SC0077	SLZ9464-A1	IVSI
7SC0082	5500-8340N1L	TURN & BANK INDICATOR
7SC0083	VIL-OC7D	HYDRAULIC PRESSURE INDICATOR
7SC0091	31007-B1	OVERSPEED WARNING SWITCH
7SC0091-1	201140-09211	OVERSPEED WARNING SWITCH
7SC0092	245050	DE-ICE PRESSURE INDICATOR
7SC0093	213-25-150-01	PRESSURE TRANSDUCER
7SC0097	VT-0107H	HYDRAULIC PRESS TRANSMITTER
7SC0098	418-09064	TORQUE PRESSURE TRANSMITTER
7SC0113	3D1472-11	DE-ICE TIMER
7SC0123	ST-12S-1	POSITION TRANSMITTER
7SC0162	U1388/6	GENERATOR CONTROL UNITS
7SC0224	92456	HYDRAULIC GAUGE



70-0180-3
DIMMER CONTROL



393008-053
FUEL QUANTITY INDICATOR



7SC0123
POSITION TRANSMITTER



35761260-8001
PROP RPM INDICATOR

AVAILABLE FOR SALE, EXCHANGE OR MRO




INVENTORY SUPPORTED MAINTENANCE, REPAIR AND OVERHAUL

[DEHAVILLAND DH-7]



1826-1
DC LAMP DIMMER



23080
STARTER GENERATOR



C-14A
DIRECTIONAL GYRO



124-1027
VOLT AMMETER

AVAILABLE FOR SALE, EXCHANGE OR MRO

PART NUM.	ALT PART NUM.	DESCRIPTION
7SC0230	18-2100-2, -3	OIL PRESSURE INDICATOR
7SC0231	8DJ163LYM4	TURBINE TEMPERATURE INDICATOR
7SC0232	DSN1967-1, -3, -5	ENG GAS GENERATOR TACH
7SC0233	8DJ181LWD2	TORQUE PRESSURE INDICATOR
7SC0236	DSF1291-6	FUEL FLOW INDICATOR
7SC0254	BTM-503	BATTERY TEMPERATURE MONITOR
7SC0269	522106	FLAP POSITION INDICATOR
7SC0284	13TX-0015-A	POSITION TRANSMITTER
7SC0292	521716	FLAP POSITION INDICATOR
7SC0365	8047/10DH	ALTIMETER
BA-141	4016341-905	SERVO ALTIMETER
C-14A	2587193-43	DIRECTIONAL GYRO
DH1030-24-1200-CS		STATIC INVERTER
PC-SERIES		STATIC INVERTERS
RD-444	2592920-444	HORIZONTAL SITUATION INDICATOR

[EMBRAER 120 CAPABILITIES]

PART NUM.	ALT PART NUM.	DESCRIPTION
056-0023-08		TURN & BANK INDICATOR
10026-0000-01		FUEL QUANTITY MASTER INDICATOR
10026-0000-02		FUEL QUANTITY MASTER INDICATOR
10027-0000-01		FUEL QUANTITY REPEATER IND
10055-0000-02		FUEL QUANTITY MASTER INDICATOR
10056-0000-01		FUEL QUANTITY REPEATER IND
10-1085-4		PASSENGER SERVICE UNIT
120-24903-501		STEERING HANDLE
120-28093-001		FUEL CONTROL PANEL
120-28093-501		FUEL CONTROL PANEL
120-29833-XXX		FLAP SELECTOR LEVER
120-30151-XXX		EFIS OVERHEAT ALARM PANEL
120-37995-001		STEERING HANDLE
120-42621-001		PRESSURE REFUEL PANEL
120-42642-XXX		FLAP SELECTOR LEVER

PART NUM.	ALT PART NUM.	DESCRIPTION
120-44590-XXX		FLAP SELECTOR LEVER
120-48260-001		MAP HOLDER ASSEMBLY
120-64199-001		LOW SPEED ALARM PANEL
120-64199-501		LOW SPEED ALARM PANEL
120-IN-0041		T6 TURBINE TEMPERATURE IND
120-IN-0042	SEDL-OC2L	TORQUE PRESSURE INDICATOR
120-IN-0044	SEL-OC29DG	NH/NL PERCENT RPM INDICATOR
120-IN-0046	SEDL-OC4BC	OIL PRESS/OIL TEMP INDICATOR
120-IN-0047	SEL-OC29DH	PROPELLER TACH INDICATOR
120-IN-0048	DGL-OC119D	OUTSIDE AIR TEMPERATURE IND
120-IN-0056		BATTERY TEMPERATURE INDICATOR
120-IN-0067	SEDL-OC29J	NH/NL PERCENT RPM INDICATOR
120-IN-0068	SEDL-OC2R	TORQUE PRESSURE INDICATOR
124.1023		HYDRAULIC FLUID INDICATOR
124.1024		HYDRAULIC PRESSURE INDICATOR
124.1025		APU TACH INDICATOR
124.1026	020-IN-0056	APU EGT INDICATOR
124.1027		VOLT/AMMETER
124.1028		COCKPIT & CABIN TEMP INDICATOR
124.1062		BATTERY TEMPERATURE INDICATOR
15900-1410		CABIN DIFFERENTIAL PRESS IND
1625-1		TEMP CONTROLLER
1632-1		DE-ICE TIMER
18.994(-1)		LIGHTING INVERTER
18.996(-1)		LIGHTING INVERTER
1822-397LW		BATTERY TEMPERATURE INDICATOR
1825-101LW		HYDRAULIC PRESSURE INDICATOR
1825-102LW		VOLT/AMMETER
1826-1	VARIOUS	5 VOLT DIMMER
211C117-183		PRESSURE SWITCH
211C119-168		REFUELING PRESSURE SWITCH
2-1479		BRAKE ASSEMBLY
2-1479-1		BRAKE ASSEMBLY
2-1661		BRAKE ASSEMBLY
23080-SERIES		STARTER GENERATORS

AVAILABLE FOR SALE, EXCHANGE OR MRO



120-37995-001
STEERING HAND WHEEL



10026-0000-02
FUEL QUANTITY MASTER
INDICATOR



10026-0000-01
FUEL QUANTITY
MASTER INDICATOR



120-IN-0046
OIL TEMP INDICATOR



Collins Aerospace

Authorized Dealer / Distributor


Hydraulics without exertion.

PHP
PRECISION HELIPARTS
A **PAG** Company

Call 404.768.9090 or visit us at
heliparts.com

Avionics
Accessories
Instruments
Wheels & Brakes
Starter Generators

Others sell parts, WE SELL SUPPORT™



Inventory Supported
Maintenance • Repair • Overhaul

[EMBRAER 120]

PART NUM.	ALT PART NUM.	DESCRIPTION
23081- SERIES		STARTER GENERATORS
24929-951		ENCODING ALTIMETER
24929-J2002		ENCODING ALTIMETER
251ECF	504-0005-901	GYRO HORIZON
28704-E2101		ENCODING ALTIMETER
28704-F2101		ENCODING ALTIMETER
28DKL4Y250		IMPACT SWITCH
30-1033-55		ROTATING BEACON
30-231-3		SMOKE DETECTOR
30-2438-1		TAIL POSITION NAV LIGHT ASSY
30-326-1		SMOKE AMPLIFIER
306999-1005	569-230	FLAP POSITION INDICATOR
306999-1007		FLAP POSITION INDICATOR
39948-E2803		MAX ALLOWABLE AIRSPEED IND
39948-E2904		MAX ALLOWABLE AIRSPEED IND
3D2376-06		EJECTOR VALVE
3E1219-4		PROPELLER DE-ICE AMMETER
3E1443-5 OR -7	RA1543-5 OR -7	PROP DE-ICE BRUSHES
3E2044-1	RA2144-1	PROP DE-ICE BRUSH ASSEMBLY
43010-E2300		VERTICAL SPEED INDICATOR
4E1188-5	RA1288-5	PROP DE-ICE BOOT
501-1197-09		GYRO HORIZON
501-1197-09A		GYRO HORIZON
501-1228-04		EMERGENCY POWER SUPPLY
5090-1		REMOTE AUDIO UNIT
5090-1-2		REMOTE ELECTRIC UNIT
5091-1-SERIES		AUDIO CONTROL PANEL
5095-1-SERIES		PA & INTERPHONE AMPS
5096-1-SERIES		CABIN INTERPHONES
51539-014A		GENERATOR CONTROL UNIT
5190-1-1		REU
519-28704-E2101	28704-E2101	ENCODING ALTIMETER
519-28704-F2101		ENCODING ALTIMETER
519-287404-F2101		ENCODING ALTIMETER
520-3337-219		RADIO MAGNETIC INDICATOR

AVAILABLE FOR SALE, EXCHANGE OR MRO



9-441-01.002
FUEL TOTALIZER
INDICATOR



120 9-464-41
FUEL FLOW RATE
INDICATOR



120 522297
COCKPIT TEMP INDICATOR



120 522540
HYDRAULIC PRESSURE
INDICATOR



522543
APU EGT INDICATOR



522545
BATTERY TEMPERATURE
INDICATOR



30699-1007
FLAP POSITION INDICATOR



43010-E2300
VERTICAL STATUS
INDICATOR

AVAILABLE FOR SALE, EXCHANGE OR MRO

PART NUM.	ALT PART NUM.	DESCRIPTION
522540		HYDRAULIC PRESSURE INDICATOR
522541		VOLT/AMMETER
522542		CABIN TEMPERATURE INDICATOR
522543		APU EGT INDICATOR
522544		APU RPM INDICATOR
522545		BATTERY TEMPERATURE MONITOR
522840		HYDRAULIC FLUID QUANTITY IND
523271	120-IN-0056	BATTERY TEMPERATURE INDICATOR
523297		COCKPIT & CABIN TEMP IND
54B		COCKPIT/CABIN TEMP SENSOR
54B2		OUTSIDE AIR TEMP SENSOR
5560-8505N3L		TURN & BANK INDICATOR
5560-8505N3LX		TURN & BANK INDICATOR
5560-8505N7L		TURN & BANK INDICATOR
562-937	3E1219-4	PROPELLER DE-ICE AMMETER
563-230		FLAP POSITION INDICATOR
563-282		FLAP POSITION INDICATOR
570-23932-981	23932-981	ENCODING ALTIMETER
570-24929-951	24929-951	ENCODING ALTIMETER
570-24929-J2002	24929-J2002	ENCODING ALTIMETER
5930-2-000		IMPACT SWITCH
60-2799-1		STROBE POWER SUPPLY
602RC-1		VERTICAL SPEED INDICATOR
622-2506-003		RADIO MAGNETIC INDICATOR
622-2506-006		RADIO MAGNETIC INDICATOR
720-15900-1410	15900-1410	TRIPLE INDICATOR
720-15900-410	15900-410	TRIPLE INDICATOR
9-441-01		FUEL TOTALIZER INDICATOR
9-441-08		FUEL TOTALIZER INDICATOR
9-464-09		FUEL FLOW INDICATOR
9-464-25		FUEL FLOW INDICATOR
9-464-41		FUEL FLOW RATE INDICATOR
AI-804 A/H		GYRO HORIZON
AI-804AH	501-1197-09	ATTITUDE GYRO
APTE-24-1000-5000A		PRESSURE TRANSDUCER

PART NUM.	ALT PART NUM.	DESCRIPTION
B13-944.22.05.1.AL		8 DAY CLOCK
D3337L-B-2-1-F		RADIO MAGNETIC INDICATOR
D366-04-001		EMERGENCY LIGHT BATTERY PACK
DGL-OC119D		OUTSIDE AIR TEMP INDICATOR
G8400A24-24		ROTATING BEACON
MS28038-1		COCKPIT/CABIN TEMP SENSOR
PC-251-1C		STATIC INVERTER
PS-835D	501-1228-04	EMERGENCY POWER SUPPLY
RCA56-14	056-0023-08	TURN & BANK INDICATOR
RMI-36		RADIO MAGNETIC INDICATOR
SEDL-OC29BJ		DUAL RPM INDICATOR
SEDL-OC29J		NH/NL PERCENT RPM INDICATOR
SEDL-OC29M		NH/NL PERCENT RPM INDICATOR
SEDL-OC2D		ENGINE TORQUE INDICATOR
SEDL-OC2L		ENGINE TORQUE INDICATOR
SEDL-OC2R		ENGINE TORQUE INDICATOR
SEDL-OC2RX		ENGINE TORQUE INDICATOR
SEDL-OC4AJ		OIL PRESSURE/TEMP INDICATOR
SEDL-OC4AU		OIL PRESSURE/TEMP INDICATOR
SEDL-OC4BC		OIL PRESSURE/TEMP INDICATOR
SEDL-OC4BE		OIL PRESSURE/TEMP INDICATOR
SEL-OC19AU		T6 TURBINE TEMP INDICATOR
SEL-OC19CA		T6 TURBINE TEMP INDICATOR
SEL-OC19EA		T6 TURBINE TEMP INDICATOR
SEL-OC19EC		T6 TURBINE TEMP INDICATOR
SEL-OC19EG		T6 TURBINE TEMP INDICATOR
SEL-OC29AU		PROPELLER RPM INDICATOR
SEL-OC29BJ		NH/NL PERCENT RPM INDICATOR
SEL-OC29DG		NH/NL PERCENT RPM INDICATOR

AVAILABLE FOR SALE, EXCHANGE OR MRO



522541
VOLT AMMETER



39948-E2803
MAX ALLOWABLE
AIRSPEED INDICATOR



30699-1007
FLAP POSITION INDICATOR



120-IN-0068
TORQUE PRESS INDICATOR

[DORNIER 228]

DORNIER 228

AVAILABLE FOR SALE, EXCHANGE OR MRO

[DORNIER 228]

PART NUM.	ALT PART NUM.	DESCRIPTION
060-0013-01		DIRECTIONAL GYRO
200DCFM	505-0010-904	DIRECTIONAL GYRO
200SGL118Q		STARTER GENERATOR
208-906-001		ITT INDICATOR
213100	5485-066	ACTUATOR
217-12261		TORQUE PRESSURE INDICATOR
23048-233		STARTER GENERATOR
23079-005		STARTER GENERATOR
23081-SERIES		STARTER GENERATORS
251ECF	504-0005-901	GYRO HORIZON
261-926-001		OIL PRESS AND TEMP INDICATOR
267-960-001		RPM INDICATOR
267-961-001		TORQUE PRESSURE INDICATOR
2800-SERIES		TURN & BANK INDICATOR
2C27-2		FUEL PUMP CARTRIDGE
332D-11T		VERTICAL GYRO
3567749-9402		OIL PRESSURE TRANSMITTER
3571220-6012		FUEL PRESSURE INDICATOR
3571220-6015		OIL PRESSURE INDICATOR
3E1150-SERIES		DE-ICE TIMERS
4020531-130		GYRO HORIZON INDICATOR
4020531-330		GYRO HORIZON INDICATOR
4099B	4000784-8501	TURN & BANK INDICATOR
4099BL	4000784-8503	TURN & BANK INDICATOR
47B43C		OUTSIDE AIR TEMPERATURE IND
4A16.32.40F.00.0.H		VERTICAL SPEED INDICATOR
4E1188-6	RA1288-6	PROP DE-ICE BOOT
500ECF	504-0002-902	GYRO HORIZON
501-1121-01		VERTICAL GYRO
510-29B		GYRO HORIZON
51530-007D		GENERATOR CONTROL UNIT
570-24929-402		ENCODING ALTIMETER
8DJ48FAL2		FLAPS PERCENT INDICATOR

PART NUM.	DESCRIPTION
135-01226-401	BACKUP BATTERY RELAY BOX
145-21285-401	IDLE LOCK BRACKET ASSEMBLY
145-21285-403	IDLE LOCK BRACKET ASSEMBLY
145-21325-405	ELECTRICAL SYSTEM CONTROL MODULE ASSEMBLY
145-21328-401	WINDSHIELD WIPER MODULE
145-21330-SERIES	APU CONTROL MODULE ASSEMBLY
145-21335-401	NAVIGATIONAL LIGHTS CONTROL MODULE
145-21339-401	FIRE CONTROL OVERHEAD PANEL MODULE ASSEMBLY
145-21340-401	STALL PROTECTION MODULE
145-21343-SERIES	RH PANEL LIGHT CONTROL MODULE
145-21344-401	LH PANEL LIGHT CONTROL MODULE
145-21345-401	REVERSIONARY PANEL MODULE
145-21347-401	REFUELING/DEFUELING PANEL ASSEMBLY
145-21353-SERIES	TRIM CONTROL MODULE
145-21456-407	ELECTRICAL PANEL ILLUMINATION PANEL
145-21459-407	ENGINE PANEL ILLUMINATION PANEL
145-22301-401	AIR CONDITIONING VALVE ASSEMBLY
145-22756-409	ENGINE HARNESS (W407)
145-25074-401	PASSENGER OXYGEN CONTROL MODULE
145-25697-SERIES	AIR DISTRIBUTION VALVE
145-25724-401	TAKE-OFF WARNING TEST MODULE
145-26715-401	OBSERVER AUDIO MODULE ASSEMBLY
145-29936-401	BACKUP BATTERY RELAY BOX
145-30503-401	POWERPLANT CONTROL MODULE ASSEMBLY
145-30709-405	LEFT DC DISTRIBUTION BOX
145-30767-401	ICU MODULE ASSEMBLY
145-31116-401	MAIN BATTERY 1 RELAY BOX
145-31625-SERIES	AIR COND/PNEUMATIC CONTROL MODULE
145-31627-407	AIR COND/PNEUMATIC CONTROL ILLUM ASSEMBLY
145-31656-SERIES	ICE PROTECTION MODULE
145-31658-407	ICE PROTECTION ILLUMINATION PANEL
145-32126-403	AVIONICS POWER DIODE BOX
145-33022-SERIES	SPOILER CONTROL UNIT
145-34145-401	WINDSHIELD WIPER CONTROL MODULE
145-34154-401	WINDSHIELD HEATING CONTACTOR BOX ASSEMBLY

AVAILABLE FOR SALE, EXCHANGE OR MRO



570-24929-01
ENCODING ALTIMETER



PW-0722-KTD-CP-1
TACH INDICATOR



GH-14 SERIES
DIRECTIONAL GYRO



9551 SERIES
TWO INCH TURN &
BANK INDICATOR


Authorized **LORD** Distributor



Call 617.3198.3660 or visit us at
precisionaviationgroup.com/php-au

Avionics
Hydraulics
Instruments
Wheels & Brakes
Starter Generators

Others sell parts, WE SELL SUPPORT™



Inventory Supported
Maintenance • Repair • Overhaul

[ERJ 135/140/145]

PART NUM.	DESCRIPTION
145-34172-401	STALL PROTECTION MODULE
145-34177-SERIES	TRIM CONTROL ASSEMBLY
145-35259-401	LH LIGHT PANEL MODULE ASSEMBLY
145-35260-401	RH LIGHT PANEL MODULE ASSEMBLY
145-41385-403	BACKUP BATTERY RELAY BOX
145-42151-401	BACKUP BATTERY RELAY BOX
145-78730-901	STOW & TRANSIT SWITCH
145-78731-901	UPPER DEPLOY SWITCH
145-78732-901	LOWER DEPLOY SWITCH
1826-1	PANEL LIGHTING DIMMER
20-017500	PEDAL POSITION TRANSDUCER
211C119-168	REFUELING PRESSURE SWITCH
214C40-1-83	ALTIMETRIC PRESSURE SWITCH
2238-0001-001	BLEED VALVE ASSEMBLY
2241-0001-001	CHECK VALVE ASSEMBLY
23034925	ABSOLUTE PRESSURE TRANSDUCER
23080-013	DC STARTER GENERATOR
2903-0002-001	FEEDER PROTECTION RELAY
29529-002	TEMPERATURE SENSOR ASSEMBLY
3000-450-21	THERMOSTAT
30-1033-63	LOWER STROBE LIGHT
30-1033-SERIES	STROBE LIGHT ASSEMBLY
30-2437-1	FORWARD POSITION NAV LIGHT ASSEMBLY
30-2437-2	NAV LIGHT ASSEMBLY
30-2438-1	TAIL POSITION NAVIGATIONAL LIGHT ASSEMBLY
30-2510-SERIES	EMERGENCY WING/FUELAGE LIGHT ASSEMBLY
30-2667-1	WING TIP STROBE ASSEMBLY
30-2667-3	STABILIZER STROBE LIGHT ASSEMBLY
30-2675-1	STROBE LIGHT ASSEMBLY
30-2676-1	LIGHT ASSEMBLY
50-0291-1	TAXI/LANDING LIGHT ASSEMBLY
501-1228-04	EMERGENCY POWER SUPPLY
5483-1-8	ATTENDANT HANDSET INTERPHONE ASSEMBLY

AVAILABLE FOR SALE, EXCHANGE OR MRO

30-1033-5
STROBE LIGHT1826-1
DC LAMP DIMMER78730-901 002
STOW AND
TRANSIT SWITCH145-IP-06
PRESSURE SWITCH

INVENTORY SUPPORTED MAINTENANCE, REPAIR AND OVERHAUL

[FAIRCHILD METROLINER]



4099B
TURN & BANK INDICATOR



23078-SERIES
STARTER GENERATOR



200DC
DIRECTIONAL GYRO



27-66006-1
FUEL PRESSURE INDICATOR

AVAILABLE FOR SALE, EXCHANGE OR MRO

PART NUM.	ALT PART NUM.	DESCRIPTION
060-00015-000		GYRO
101635-01697L		ENCODING ALTIMETER
124.511		TORQUE PRESSURE INDICATOR
124.511-2		TORQUE PRESSURE INDICATOR
12S5000-1		DC VOLTMETER
1532-SERIES		DE-ICE DISTRIBUTION VALVES
1C49-3 OR -5		FUEL BOOST PUMP
200DC(28)	505-0002-904	DIRECTIONAL GYRO
200DCL(28)	505-0010-902	DIRECTIONAL GYRO
SERIES	27-19193-SERIES	MAX ALLOW AIRSPEED INDICATORS
205-1BL		DIRECTIONAL GYRO
2-1203-2/3		BRAKE ASSEMBLY
22-281-023		TACH INDICATOR
22702-032		ENCODING ALTIMETER
22702-SERIES	519-22702-SERIES	ENCODING ALTIMETER
23069-SERIES		STARTER GENERATORS
23079-SERIES		STARTER GENERATORS
27-19139-001	30260-1166	IVSI
27-19144-00X	563-0XX	AWI QUANTITY INDICATOR
27-19145-XXX	563-XXX	CABIN AIR TEMP INDICATORS
27-19149-00X	61104-0X	EGT INDICATOR
27-19157-00X	61111-XX	PERCENT TACH INDICATOR
27-19158-00X	61121-0X	PERCENT TORQUE INDICATOR
27-19160-00X	563-XXX	OIL PRESSURE & TEMP INDICATOR
27-19161-00X	563-XXX	FUEL PRESSURE INDICATOR
27-19162-003	DSF1546-7	FUEL TOTALIZER
27-19163-00X	DSF1549-X	FUEL FLOW INDICATOR
27-19164-005	82-107-4	DUAL FUEL QUANTITY INDICATOR
27-19164-007	61461-01	DUAL FUEL QUANTITY INDICATOR
27-19164-0XX	82-107-XX	FUEL QUANTITY INDICATOR
27-19167-001	VARIOUS	TURN & BANK INDICATOR
27-19173-001	61101-09	ITT INDICATOR
27-19174-001	61121-02	TORQUE PRESSURE INDICATOR
27-19175-001	61111-12	PERCENT TACH INDICATOR
27-19175-00X	100-0043-0X	PROPELLER TACH INDICATOR

PART NUM.	ALT PART NUM.	DESCRIPTION
27-19177-002		OIL PRESSURE & TEMP INDICATOR
27-19178-001	2490-727	FUEL PRESSURE INDICATOR
27-19193-SERIES	20130-11-SERIES	MAX ALLOW AIRSPEED INDICATORS
27-19216-005	AG44AF	TACH GENERATOR
27-19313-001	SEL-OC19ET	EGT INDICATOR
27-66004-00X	DST-29-XX	ITT INDICATOR
27-66004-0XX		ITT INDICATOR
27-66006-1	217-17241	FUEL PRESSURE INDICATOR
27-66007-1	DSF684-1	FUEL QUANTITY INDICATOR
27-66008-001		OIL PRESSURE INDICATOR
27-66008-003		TORQUE PRESSURE INDICATOR
27-66008-5	27-66008-005	OIL PRESSURE INDICATOR
27-66010-00X		TORQUE PRESSURE INDICATOR
27-66010-9	124.511-1	TORQUE PRESSURE INDICATOR
27-66108-XXX		TORQUE PRESSURE INDICATOR
27-82186-SERIES		LANDING GEAR POSITION IND
2800(4530N13L)	2800 (4530N11L)	TURN & BANK INDICATOR
28702-XXX		ENCODING ALTIMETER
35918/61111-14		PERCENT TACH INDICATOR
4000784-850X		TURN & BANK INDICATOR
40-0100-SERIES		OSCILLATING BEACONS
4099B	4000784-85XX	TURN & BANK INDICATOR
4099BL	4000784-8503	TURN & BANK INDICATOR
418-00054	418-00051	OIL PRESSURE TRANSMITTER
418-01014		FUEL PRESSURE TRANSMITTER
418-12004		FUEL PRESSURE TRANSMITTER
5007396-2		BRAKE ASSEMBLY
500DCF		GYRO HORIZON
500DC-SERIES	504-0010-SERIES	GYRO HORIZONS
500ECFL-2A	504-0021-908	GYRO HORIZON
5011640-1/2		BRAKE ASSEMBLY
5035P P.22		ENCODING ALTIMETER
5035P-SERIES	VARIOUS	ENCODING ALTIMETERS
504-0010-90X		GYRO HORIZON
504-0017-9XX		GYRO HORIZON

AVAILABLE FOR SALE, EXCHANGE OR MRO



61104-03
EGT INDICATOR



500DC
HORIZON GYRO



61101-09
ITT INDICATOR



217-0621
TORQUE INDICATOR



328A
SLAVING GYRO



332D-11
VERTICAL GYRO



9302333-001
DC-VOLT/AMMETER



9302296-002
MAX ALLOWABLE
AIRSPEED INDICATOR

AVAILABLE FOR SALE, EXCHANGE OR MRO

PART NUM.	ALT PART NUM.	DESCRIPTION
23080-SERIES		STARTER GENERATORS
30012-0000-04	30012-0000-04	FUEL QUANTITY SIGNAL COND
5012589-2		MAIN WHEEL ASSEMBLY
72EPF2014-1	9-231-07	FUEL FLOW TRANSMITTER
72EPF3007-1	60-3757-1	STROBE SUPPLY
72ESF2013-X	522814	TOTAL FUEL USED INDICATOR
72ESF2014-1	9-231-07	FUEL FLOW TRANSMITTER
72PPF9102-3	RR54520A	FUEL BOOST PUMP
9302236-001	51539-007A	GENERATOR CONTROL UNIT
9302251-001	449-2	DIMMER
9302262-002	10251N01T00	ITT INDICATOR
9302270-00X	ASH500-1P	STATIC INVERTER
9302274-001	60-1321-1	EMERGENCY BATT POWER SUPPLY
9302277-001	G9950-1	BEACON
9302279-001	501-1318-01	SC841A INVERTER
9302296-002	64060-890-1	MAX ALLOWABLE AIRSPEED IND
9302300-001	64089-360-1	VERTICAL SPEED INDICATOR
9302301-001	64111-900-1	COUNTER POINTER ALTIMETER
9302328-001	522406	DC VOLT/AMMETER
9302333-001	64141-360-1	COUNTER POINTER ALTIMETER
9302337-00X		CABIN AIR TEMPERATURE IND
9302342-00X		TRIM POSITION INDICATOR
9302349-001	64141-370-1	COUNTER POINTER ALTIMETER
9302350-002	522783	CABIN PRESSURIZATION INDICATOR
9302391-00X		DUAL HYDR BRAKE PRESS IND
9302392-003	523250	DUAL HYDR BRAKE PRESS IND
9302393-001	522396	HYDRAULIC QUANTITY LEVEL IND
9302413-00X	H341ADM(X)	GYRO HORIZON
9302414-001	501-1228-04	EMERGENCY POWER SUPPLY
9302426-003	D3337L/B21S/SB1	RMI
9302471-003	522858	DUAL FLAP POSITION INDICATOR
9302472-004	522823	TORQUE PRESSURE INDICATOR
9302473-002	522792	PROPELLER TACH INDICATOR
7SC0232	DSN1967-1, -3, -5	ENG GAS GENERATOR TACH
7SC0233	8DJ181LWD2	TORQUE PRESSURE INDICATOR

[SHORTS 330/360]

PART NUM.	ALT PART NUM.	DESCRIPTION
101435-11719		ENCODING ALTIMETER
114.069-6		HYDRAULIC TEMP INDICATOR
124.132		VOLT/AMMETER
124.210-1 OR -2		FLAP POSITION INDICATORS
124.551-7 OR -9		ITT INDICATORS
124.552-1 OR -2		OIL PRESSURE/TEMPERATURE IND
224-917-012		PROP TACH INDICATOR
23046-007		STARTER GENERATORS
2CM9ABH-7		TACH GENERATOR
396-09730		TORQUE PRESSURE INDICATOR
3E1150-SERIES		DE-ICE TIMERS
3E1443-5 OR -7		PROP DE-ICE BRUSHES
3E2090-1		PROP DE-ICE BRUSH ASSEMBLY
418-04034		TORQUE PRESSURE TRANSMITTER
4358-10XX		HYDRAULIC PRESSURE INDICATOR
504-0017-SERIES		GYRO HORIZONS
50647-3 OR -4		FLAP POSITION TRANSMITTERS
510-SERIES		GYRO HORIZONS
51509-004A		GENERATOR CONTROL UNIT
522-2638-006	331A-3G	HSI/COURSE INDICATOR
522-2644-011	328A-3G	SLAVING ACCESSORY
522-3241-000	3.32E-02	SLAVED DIRECTIONAL GYRO
617-07431		TORQUE PRESSURE INDICATOR
622-2506-003		RMI-36
622-4565-SERIES	332D-11	VERTICAL GYROS
622-6136-002	DGS65	SLAVED DIRECTIONAL GYRO
710-920		FUEL QUANTITY INDICATOR
8DJ81WCR4		TACH INDICATOR
AH52998		MAIN WHEEL
AR-207-1		FUEL FLOW RATE INDICATOR
ASH-SERIES		STATIC INVERTERS


AVAILABLE FOR SALE, EXCHANGE OR MRO



3E1150-10
ELECTRICAL
DE-ICE TIMER




330 124-210-1
FLAP POSITION INDICATOR



2CM9ABH7
TACH GENERATOR



101435-11719
AIRSPEED INDICATOR



We have also generated
an impressive following.

PHP
PRECISION HELIPARTS LATIN AMERICA
A **PAG** Company

Call 55.11.4186.6116 or visit us at
precisionaviationgroup.com/php-br

Avionics
Hydraulics
Accessories
Instruments
Wheels & Brakes

Others sell parts, WE SELL SUPPORT™



Inventory Supported
Maintenance • Repair • Overhaul

[WARRANTY & RETURN POLICIES]

Warranty Policy

Precision Aviation Group (PAG) warrants each instrument or aircraft accessory to be free from defects in material and workmanship under normal usage, providing installation and handling have been conducted in a professional manner. PAG warrants all instrument exchanges and overhauls for one (1) year or three hundred (300) hours of operation, whichever comes first. The defective unit will be repaired or replaced at PAG's discretion once the unit is returned and the malfunction is verified. After the repair or replacement, the item will retain the unused portion of the original warranty. That warranty will be void if seals are broken. Warranty will be void on vacuum gyros if foreign matter, such as carbon or oil, is found upon disassembly.

Limitation of Warranty

The above warranty shall be the sole and exclusive remedy. The foregoing warranty is limited and exclusive. PAG makes no other warranty, expressed or implied, of merchantability or fitness for a particular purpose. In no event will PAG be liable for resultant damage, loss of use, or consequential damages.

Return Policy

Any unit purchases from PAG may be returned for credit, in its original unopened packaging, via appropriate shipping methods within seven (7) days of the purchase at its original price less a 25% restocking fee. If the unit is purchased from a third-party vendor by PAG on behalf of the customer, PAG reserves the option to invoice the customer for any restock fees charged by the third-party vendor. PAG reserves the option to invoice the customer for costs incurred in the re-certification of any unit returned for credit. If any unit returned for claimed warranty is found to be functional with no defects, PAG reserves the option to invoice the customer for cost incurred in the re-certification of that unit.

WE ACCEPT ALL MAJOR CREDIT CARDS



[PAG EXCHANGE AGREEMENT]

Company Name: _____

Address: _____

This Exchange Agreement (Agreement) between Precision Aviation Group, Inc. including its subsidiaries and affiliates ("PAG"), and the company listed above ("Customer") governs all exchange transactions between the parties. Unless the parties enter into a different agreement, this Agreement will apply to all exchange transactions between the Customer and PAG, and shall remain in effect indefinitely unless it is superseded by another agreement entered into by both parties or rescinded by PAG. If it becomes necessary to change this Agreement or the offering terms of this Agreement need to be rescinded by PAG, written notification shall be given to the Customer. In relation to material exchanges between PAG and the Customer, this Agreement supersedes all previous agreements and acceptance of it by the Customer renders all previous agreements null and void. Notwithstanding the forgoing, the terms and conditions of PAG's invoices to Customer shall also apply to any transactions between the parties, and the terms of such invoices shall be interpreted consistent with and subject to this Agreement.

BILLING

The Customer will be charged an exchange price as quoted by PAG for each exchange transaction. The Customer will also be advised of and billed a core charge. This core charge will represent the amount that the Customer will owe PAG above and beyond the exchange price if a core of equal or greater value is not returned or the returned core is unacceptable. The core charge will be credited to the Customer's account upon receipt and acceptance of the core by PAG. The exchange price is based on a like core (a repairable core of the same model and same part number as the unit supplied by PAG), being returned in an economical condition as determined by PAG in its sole discretion. Cores which have been subjected to use or damage constituting more than the normal "wear and tear" will be returned "As-Is" to the customer or subject to additional charges. Cores returned that are found to be Beyond Economical Repair (BER) will be subject to invoice to the Customer at full price. PAG may, in its sole discretion, offset any amounts it may owe Customer or Customer affiliates in the event Customer or Customer affiliates fail to pay any amounts when due. PAG may also retain and resell any core units or other materials that the Customer or Customer affiliates provided to PAG to offset any amounts due. Notwithstanding the forgoing, PAG reserves all rights in law or equity it may have in addition to those set forth herein.

CORE CONDITIONS

PAG defines a repairable core as a unit that is in the condition as removed from an aircraft, a unit that is not incident related (i.e. no fire or water damage) and a unit that can be economically repaired. If the cost to repair the core exceeds 75% of the flat rate charge, the unit may be deemed to be BER. Furthermore, PAG will not accept the following:

- Cores that have been heavily modified or extensively and unproductively worked on.
- Cores with missing, modified or illegible data plates.
- Cores that arrive disassembled.

CORE RETURNS

All cores shall be returned to PAG [see specific subsidiary or affiliate address on invoice]. Any and all transportation costs for the return of the core are the responsibility of the Customer. Customer exchange cores are to be returned to PAG within 30 days. Core units not returned within 30 days may, at the discretion of PAG, be subject to an additional charge of 2% of the outright sale price per day. If no core is returned after 45 days, Customer shall be in default under this Agreement, and PAG shall conclude that no core will be sent, and the Customer will be obligated to pay PAG the full core charge immediately without further demand. If the Customer later chooses to return a core after 45 days, PAG's acceptance of such core is subject to approval by PAG in its sole discretion, including the amount of any credit to be applied to Customer account for the past due core as PAG may incur additional costs as a result of not receiving the core within 45 days.

Original exchange units returned for credit after seven days may, at the discretion of PAG, be subject to a restocking fee of 25% of the exchange price or \$175.00 (whichever is greater). In addition to the restocking fee, the cost to recertify the returned unit may also be assessed if the original certification is not returned.

OTHER

Both Customer and PAG agree that if any provision of this Agreement is unenforceable, that provision either may be enforced to the maximum extent allowed by law, modified as necessary to make it fully enforceable, or considered severed from this Agreement. Customer and PAG further agree that any unenforceable provision does not invalidate any other provision of this Agreement, or the Agreement in its entirety, and the parties agree that they will continue to fulfill all other obligations hereunder. This Agreement shall be governed by and construed in accordance with the laws of the State of Georgia, USA, without regard to the conflict or choice of law provisions thereof, and Customer consents to the jurisdiction of the state and federal courts in and for Fulton County, Georgia for all disputes arising out of or related to this Agreement.

The undersigned parties agree to all of the conditions set forth in this Exchange Agreement.

PRECISION AVIATION GROUP, INC.

Signature: _____

Print Name & Title: _____

Date Signed: _____

CUSTOMER

Signature: _____

Print Name & Title: _____

Date Signed: _____

Email Completed Form to exagmt@ismro.com.

[PAG END USE / USER STATEMENT]

TO WHOM IT MAY CONCERN:

Compliance with United States Export Regulations

It is Precision Aviation Group's policy to verify the end use and end user of all product sales and repairs to ensure compliance with applicable U.S. export control laws and regulations. Because the products you are purchasing or having serviced could be exported and used outside of the United States, please confirm the following:

1. We will not export or re-export any Precision Aviation Group supplied products to any debarred country unless otherwise authorized by the United States Department of Commerce or Department of State.
2. We acknowledge that U.S. law prohibits the sale, transfer, export or re-export or other participation in any export transaction involving Precision Aviation Group's supplied products with individuals or companies listed in the U.S. Commerce Department's Table of Denied Orders, the U.S. Treasury Department's list of Specially Designated Nationals or the U.S. Department of State's list of individuals debarred from receiving Munitions List items.
3. We will abide by all applicable U.S. export control law and regulations for any products purchased from Precision Aviation Group and will obtain any licenses or prior approvals required by the U.S. government prior to export or re-export or Precision Aviation Group supplied products.
4. We agree that the export control requirements in No. 1-3 above shall survive the completion, early termination, cancellation or expiration of the applicable purchase order, agreement or contract.

PAG Sales Executive: _____

Company Name: _____ Postal Code: _____

One time release: Purchase Order Number: _____

If you would like a Blanket End User Form on file for 12 months, please check here: ☐ ***

End User: _____

Destination Country of end user: _____

Signature: _____ Date: _____

Print Name: _____

Title: _____

*** By checking the box, your Company name and End User name must match. By accepting a 12-month blanket statement, you are responsible for complying with all above regulations should you decide to resell the product.

The purchaser recognizes they are solely responsible for obtaining and complying with the latest information of denied parties and current shipping embargos.

Corporate Office: Precision Aviation Group - 495 Lake Mirror Road, Bldg. 800 - Atlanta, GA 30349
404-767-5800 - www.precisionaviationgroup.com

Submit Completed Form to Your Sales Executive.

PRECISIONAVIATIONGROUP.COM
404-768-9090

